							c	L			
			+	-			Training Meeting				
-	7	4	$\vdash$	450	102	ンチン	Setup				
	Inspector	Rev I	ed Mtrl o Check	Approved Yes / No	Time Of Day	Date Part Submitted	Maintenance Tooling	2 1 V			
	Part Inspection Record	First Part				STATE OF STA	Down Time Codes	D	tructions	Special Notes / Instructions	Specia
											ROUTING:
	95,5		$\parallel$								
							1				
						6	6	+	(1)	200	14/1/21
	Notes		me	Down Time Code	Down Time	Cum. Total	Total Pcs. Cur			Emp. Name	Date
		Pcs./Hr			Cycle Time	40	Setup Hrs.		, ·	Mach. No.	
							Do not require traceability.	require	Do not	Caps/Plugs	Cap
					=	ot Number.	Located on the bag followed by "Lot Number."	d on the	Locate	Snap Rings	Sna
	CP15				box label.	date on the	Use their work order number and date on the box label.	eir work	Use th	Flare Tubes	Flan
	BRZ09			١	etter "M."	ng with the l	Located on the spool label, starting with the letter "M."	d on the	Locate	Copper Tubing	Copp
	BRZ05			=	vord "heat.	above the w	Located on the box label, directly above the word "heat."	d on the	Locate	Brazing Rings	Brazi
	CUTU-0-1/4				ox quantity.	oel under bo	Six digit no. located on the box label under box quantity.	it no. loca	Six dig	Flare Nuts	Flai
	_ <del>CUTU-</del> <b>]</b> -7/8	2				nbers	Distinguishing Traceablity Numbers	tinguishi	Dis		
	7-4-12	1						3		Order Qty	Orc
_	Component(s)	S		LLC	devices, LLC	H	4	393194		Order No.	Orc
							1	7 1 1 1 CT CT C		ומונושט.	Fa