BRAZING PRODUCTION RECORD			special Notes / instructions	Coordal Mot	POLITING						11/0	ate	A	Caps/Plugs	Snap Rings	Flare Tubes	Copper Tubing	Brazing Rings	Flare Nute	Order Qty	Order No.
TON DECO			es / mstruc								0	Emp. Name	Mach. No.	SBr	SBu	bes	bing	ings	7	ltγ	lo.
9					K							Prod Hrs.		Do not req	Located or	Use their v	Located or	Located or	Disting		4
	5 Training 6 Meeting		Down Time Codes Maintenance	1							o	Total Pcs.		Do not require traceability.	Located on the bag followed by "Lot Number."	Use their work order number and date on the box label.	Located on the spool label, starting with the letter "M."	Located on the box label, directly above the word "heat."	Distinguishing Traceablity Numbers	G	400922
			Codes									Cun	Setup Hrs.	ty.	wed by "L	nber and	el, startin	, directly	blity Nun		
		Submitted	Date Part									Cum. Total			ot Numbe	date on th	g with the	above the	bers		1
		Time Of Day										Down Time	Cycle Time		r."	າe box label.	letter "M."	word "heat.			devices, LLC
		Yes / No										Down Time Code						=			LLC
		Check																	_	1	
		Rev Letter	First Part In										Pcs./Hr							703	6
	25	Inspector	Inspection Record									Notes				1		G-RING	GR5	703-9-3/16-1/2	component(s)
			T CANA			V	17/6	1					Thru- put/8hrs							Į.	
		Notes					2	6				-						N/A	N/A	100617	No(s)
					1							Scrap									
												Scrap Code									