										I I	DRAZING DROPH OTION DECORP	
									FAIR Training	4 π		
		2								3		
	Notes	r Inspector	Rev Letter	Mtrl Check	Approved Yes / No	Time Of Day	Date Part Submitted	се	MaintenanceTooling	2 1		
		Part Inspection Record	First Part					e Codes	Down Time Codes	ctions	Special Notes / Instructions	Specia
												ROUTING:
•												
+										-		
								+				
						B	1		T	Domes	477	1/11/16
Scrap Scrap Code	Sc	Notes			Down Time Code	Down Time	Cum. Total	Cur	Total Pcs.	Prod Hrs.	Emp. Name	Date
	putyonis						STORES OF STREET			A PART OF THE PART		
	Thru-		Pcs./Hr			Cycle		Setup Hrs.			Mach. No.	
		2						lity.	Do not require traceability.	Do not requ	Caps/Plugs	Caps
						=	ot Number.	owed by "L	Located on the bag followed by "Lot Number."	Located on	Snap Rings	Snap
!						box label.	date on the	ımber and	Use their work order number and date on the box label.	Use their w	Flare Tubes	Flare
						etter "M."	g with the l	bel, startin	Located on the spool label, starting with the letter "M."	Located on	Copper Tubing	Coppe
		CP13				ord "heat."	above the w	el, directly	Located on the box label, directly above the word "heat."	Located on	Brazing Rings	Brazir
		BRZ03				x quantity.	el under bo	the box lak	located on	Six digit no. located on the box label under box quantity.	Flare Nuts	Flare
	-	CUTU-1-1/2					nbers	eablity Nun	Distinguishing Traceablity Numbers	Distingu		
	296551	SF404-6-1/4	S						4		Order Qty	Orde
	No(s)	Component(s)	Ç		ררכ	devices, LLC	H		396551	68	Order No.	Ord
	Heat Lot/Traceability					7			5404-b-1/4	2404	Part No.	Par