										6 Meeting			
										5 Training			
	. is	Notes	Inspector	Rev Letter	Mtrl Check	Approved Yes / No	Time Of Day	Date Part Submitted					
			Inspection Record	First Part Ir					Codes			Special Notes / Instructions	Specia
													ROUTING:
	7												
		1											
											1		
												ı	
													(4)
				5									
										F		SB	1/24
Scrap Code	Scrap	2	Notes			Down Time Code	Down Time	Cum. Total	Cur	Total Pcs.	Prod Hrs.	Emp. Name	Date
		put/8hrs					IIme	A Charles and A Charles	rirs.	Constitution of the relative			
	, Wall	Thru-		Pcs./Hr			Cycle		Setup			Mach. No.	
						A STATE OF THE PARTY OF THE PAR					- 大学のまるの		month professional
									y.	Do not require traceability.	Do not requ	Caps/Plugs	Caps
							=	ot Number.	ed by "L	Located on the bag followed by "Lot Number."	Located on	Snap Rings	Snap
							box label.	date on the	ber and	Use their work order number and date on the box label	Use their wo	Flare Tubes	Flare
							etter "M."	g with the l	l, startin	Located on the spool label, starting with the letter "M."	Located on	Copper Tubing	Coppe
							vord "heat."	above the w	directly	Located on the box label, directly above the word "heat."	Located on	Brazing Rings	Brazin
							α quantity.	pel under bo	e box lak	Six digit no. located on the box label under box quantity.	Six digit no.	Flare Nuts	Flare
		7.99000E	E-RING					nbers	olity Nun	Distinguishing Traceablity Numbers	Distingu		
		397566	901-8-5/16	90						4		Order Qty	Orde
		No(s)	omponent(s)	Con		LLC	devices, LLC	THE STATE OF THE S		398165	39	Order No.	Orde
	bility	Heat Lot/Traceability					ontrol			901-8-5/16-R	901-8	Part No.	Par