												1.1.1
									6 Meeting			
	Notes	Inspector	Rev Letter	Mtrl	Approved Yes / No	Time Of Day	Date Part Submitted	TD.	<ol> <li>Maintenance</li> <li>Tooling</li> </ol>			
		rt Inspection Record	First Part Ir				THE WAY	Codes	Down Time Codes	tions	Special Notes / Instructions	Specia
												ROUTING:
7	F											
		01										
	0	7.5										
	•											
									Ŧ		56	3/33
Scrap Scrap	Sc	Notes			Down Time Code	Down Time	Cum. Total	Ct	Total Pcs.	Prod Hrs.	Emp. Name	Date
	putyonia					Tilling						
	Thru-		Pcs./Hr			Cycle		Setup Hrs.			Mach. No.	
								ָלָי. 	Do not require traceability.	Do not requ	Caps/Plugs [	Cap
L						=	Lot Number.	wed by "	Located on the bag followed by "Lot Number."	Located on		Snaj
						box label.	d date on the	nber and	Use their work order number and date on the box label.	Use their w	Flare Tubes	Flare
						etter "M."	ng with the I	el, starti	Located on the spool label, starting with the letter "M."	Located on	Copper Tubing	Coppe
				l .		vord "heat."	above the v	, directly	Located on the box label, directly above the word "heat."	Located on	Brazing Rings	Brazi
						ox quantity.	bel under bo	ne box la	Six digit no. located on the box label under box quantity.	Six digit no.	Flare Nuts	Flar
	70000000	E-RING					mbers	blity Nu	Distinguishing Traceablity Numbers	Distingu		
	Z/A	ER15							4		Order Qty	Ord
	No(s)	Lomponent(s)	Con		LLC	devices, LLC	H		401577	40	Order No.	Ord
	Heat Lot/Traceability					ontrol	1		ER15-R	9	Part No.	Pai