7	K
1	
1	
D	

BRAZING PRODUCTION RECORD			Specia	ROUTING:								2115	Date			Cap	Sna	Flan	Copp	Brazi	Flai		Orc	Orc	
			Special Notes / Instructions										Emp. Name		Mach. No.	Caps/Plugs	Snap Rings	Flare Tubes	Copper Tubing	<b>Brazing Rings</b>	Flare Nuts		Order Qty	Order No.	
Section 2			ictions										Prod Hrs.	ACCORDING AND		Do not req	Located on	Use their w	Located on	Located on	Six digit no	Disting		4	
	3 Setup 4 FAIR 5 Training 6 Meeting	5 6	Down Time Codes									L	Total Pcs.			Do not require traceability.	Located on the bag followed by "Lot Number."	Use their work order number and date on the box label.	Located on the spool label, starting with the letter "M."	Located on the box label, directly above the word "heat."	Six digit no. located on the box label under box quantity.	Distinguishing Traceablity Numbers	1	400359	3.0
		T.,	Codes										Cum. Total	Hrs.	Setup	, ×	ed by "Lot	ber and da	l, starting	directly ab	e box labe	olity Numb			
		Date Part Submitted											Total				Number.	ate on the	with the I	ove the v	l under bo	ers		F C	ĵ
		Time Of Day	THE THE										Down Time	Time	Cycle		а	box label.	etter "M."	vord "heat.'	ox quantity.			devices, LLC	ノンフナフン
		Approved Yes / No											Down Time Code											ררכ	
		Mtrl F Check	F																						
-	-	Rev Letter	irst Part Ins				_	1	>			1			Pcs./Hr					35	_		703-	Com	)
		Inspector	First Part Inspection Record					5	3	-	_		Notes								G-RING	GR6	703-4-5/16-1/2	Component(s)	
										X	3			put/8hrs	Thru-							T	Ī		l nedt i
		Notes														3					P			No(s)	Heat Lot/ Iraceability
					X								Scrap												-
						is							Scrap Code												