		H	1		1	FAIR Training Meeting	6 5		
V.	Notes	Rev Letter Inspector	/ No Check	Time Of Day Yes / No	Date Part Submitted	Maintenance Tooling Setup	3 2 1		
		First Part Inspection Record			Н	Down Time Codes	tions	Special Notes / Instructions	Specia
ΙÌ									ROUTING:
T									
	94								
			-						
			1						
						_	10min	V	410
Scrap		Notes	de	Down Time Code	Cum. Total	Total Pcs.	Prod Hrs.	Emp. Name	Date
	1000年十七日			STORY SERVICE STATE AND DE		Complete States of the second		The second second second	
	Thru- put/8hrs	Pcs./Hr		Cycle Time	Setup Hrs.	- Se		Mach. No.	
						Do not require traceability.	Do not requi	Caps/Plugs	Caps
		L-RING		1	y "Lot Number.'	Located on the bag followed by "Lot Number."	ocated on t		Snap
		BRZ03		box label.	and date on the	Use their work order number and date on the box label.	Use their wo	Flare Tubes	Flare
		CUTU-1-1/2		etter "M."	arting with the le	Located on the spool label, starting with the letter "M."	ocated on t	Copper Tubing	Coppe
		BRZ05		ord "heat."	ctly above the w	Located on the box label, directly above the word "heat."	ocated on t	Brazing Rings	Brazii
		CUTU-12-1/4		x quantity.	x label under bo	Six digit no. located on the box label under box quantity.	Six digit no. I	Flare Nuts	Flar
		L1/3			Numbers	Distinguishing Traceablity Numbers	Distingui		
	794677	SF405-2-1/4-1/2				1		Order Qty	Ord
١,	No(s)	component(s)		devices, LLC		394677	394	Order No.	Ord
ollity	meat Lot/ Traceability			07770	l				1 0