Test Form 11/4/15	Test i										ORD	BRAZING PRODUCTION RECORD	BRAZING PRO
				9						6 Meeting			
		(8)		A	•	7111							
		00 00	ンド		-	(36)	0 110	1-25-16		3 Setup			
	Notes	9	Inspector	Rev Letter	Check	Approved Yes / No	Time Of Day	Submitted	lance	MaintenanceTooling			
			Inspection Record	First Part Ir	Н		The State of		Down Time Codes		ctions	Special Notes / Instructions	Specia
	ę												ROUTING:
	Ş				+								
	V.	A											
		>											
		-											
	7							•		_			10111
	8						0	ľ		2	/un 10.	Y	
	()							W		رر	HS min	YE	1/26/11
Scrap Code	Scrap		Notes		ъ	Down Time Code	Down Time	Cum. Total		Total Pcs	Prod Hrs.	Emp. Name	Date /
		put/onrs					- 11110					i la	
		Thru-		Pcs./Hr			Cycle	0	Setup			Mach. No.	
					1							d	
									bility	uire tracea	Do not require traceability	Caps/Plugs	Caps
							- =	Located on the bag followed by "Lot Number."	lowed by	the bag fo	Located on	Snap Rings	Snap
			CP13				e box label.	Use their work order number and date on the box label	number an	ork order	Use their w	Flare Tubes	Flare
		7	CSW-3-1/2	S			letter "M."	Located on the spool label, starting with the letter "M."	label, starti	the spool	Located on	Copper Tubing	Coppe
	ンと	1221	BRZ22			н	word "heat.	Located on the box label, directly above the word "heat."	bel, directly	the box la	Located on	Brazing Rings	Brazir
		~	BRZ01			5.0	ox quantity.	Six digit no. located on the box label under box quantity.	n the box la	. located o	Six digit no	Flare Nuts	Flar
		·V.	TU-24-5/32-B	CUTI				mbers	Distinguishing Traceablity Numbers	uishing Tra	Disting		
	7	7	SF4-2.5-10	SI						2		Order Qty	Ord
	No(s)		omponent(s)	Con		LLC	devices, LLC	H	e2	398552	38	Order No.	Ord
	Heat Lot/Traceability	Heat Lot		,						S4-2.5-10-24-B	S4-2.	Part No.	Par
27													