Test Form 11/4/15	Test F									RD	BRAZING PRODUCTION RECORD	BRAZING PRO
									Meeting	6	SAMPLE	
									Training			
									Setup			
	Notes	Not	Inspector	Rev Letter	Mtrl Check	Approved Yes / No	Time Of Day	Date Part Submitted	Maintenance Tooling			
			First Part Inspection Record	First Part Ir				N. S.	Down Time Codes		Special Notes / Instructions	Special
												ROUTING:
	8											
	?	N										
		80.										
		214										
-			ı				e e					
	_	y						26	36	140	UC	91/12/E
Scrap Code	Scrap		Notes			Down Time Code	Down Time	Cum. Total	Total Pcs. Cu	Prod Hrs. 1	Emp. Name	Date
を表現		put/8hrs					IIme	The second second	nis.			
		Thru-		Pcs./Hr			Cycle	J	Setup		Mach. No.	
		8	CP13						traceability.	Do not require traceability.	Caps/Plugs	Caps
			L-RING	ı			=	Lot Number.	Located on the bag followed by "Lot Number."	ocated on the		Snap
			L3/4		I		box label.	d date on the	Use their work order number and date on the box label.	Jse their work	Flare Tubes	Flare
			BRZ24				etter "M."	ng with the I	Located on the spool label, starting with the letter "M."	ocated on the	Copper Tubing	Coppe
			CUTU-12-3/16	CUT		-	vord "heat."	above the v	Located on the box label, directly above the word "heat."	ocated on the	Brazing Rings	Brazin
			BRZ23				າx quantity.	abel under bo	Six digit no. located on the box label under box quantity.	six digit no. loc	Flare Nuts	Flare
			CUTU-1-1/2	5				mbers	Distinguishing Traceablity Numbers	Distinguish		
			SF403-2-3/16	SF4						25	Order Qty	Orde
		No(s)	Component(s)	Cor		ררכ	devices, LLC	H	'2	396772	Order No.	Orde
	ahilitv	Heat Lot/Traceability							)99-C	MD0201999-C	Part No.	Par