BRAZING PRO			Specia	ROUTING:										12/3	Date			Cap	Sna	Flare	Coppe	Brazi	Flar		Ord	Ord	Ра
BRAZING PRODUCTION RECORD			Special Notes / Instructions		4.0						8			SS	Emp. Name		Mach. No.	Caps/Plugs	Snap Rings	Flare Tubes	Copper Tubing	Brazing Rings	Flare Nuts		Order Qty	Order No.	Part No.
	651	4 3 2 1	ctions										1		Prod Hrs.			Do not requ	Located on	Use their w	Located on	Located on	Six digit no.	Distingu	8	39	
-1		Maintenance Tooling Setup FAIR	Down Time Codes											-	Total Pcs.			Do not require traceability.	Located on the bag followed by "Lot Number."	Use their work order number and date on the box label.	Located on the spool label, starting with the letter "M."	Located on the box label, directly above the word "heat."	Six digit no. located on the box label under box quantity.	Distinguishing Traceablity Numbers	1	392701	010
			Codes												Cum	Hrs.	Setup	×	ved by "Lo	ber and	el, starting	directly a	e box lab	blity Num			
		Date Part Submitted									ū				Cum. Total			ot Number	date on the	with the	bove the	el under b	bers		1		
		Time Of Day													Down Time	Time	Cycle		-	e box label.	letter "M."	vord "heat."	ox quantity.			devices,	control
		Approved Yes / No										1			Down Time Code			8							LLC		
		Mtrl Check																							ļ		
		First Part In:										,			Pcs./Hr	Pcs./Hr									Con		
		Inspector	Inspection Record												Notes									G-RING	G20	Component(s)	
						50									Thru- put/8hrs	Thru-							30	7		Heat Lo	
		Notes								0								4						30151504	N/A	No(s)	Heat Lot/Traceability
					\$										Scrap												<
															Scrap												