)		
								6 Meeting			
				1							
	tter Inspector	Rev Letter	oved Mtrl / No Check	Day Approved Yes / No	Time Of Day	Date Part Submitted	Ō				
The second second	art Inspection Record	First Part					Codes	Down Time Codes	ctions	Special Notes / Instructions	Specia
											ROUTING:
1											
1887	_									-	
3					Pare .						
6	Ę										
	e"				\dagger						
								۶		<i>V</i> :	./23
	140,000		de	Code	0	0	9	, O. C.		1	
			Time	Down Time	7	Total		Hatta		Nichola	Path
Thru- put/8hrs	Hr	Pcs./Hi		10 10	Cycle Time	. 6	Setup Hrs.			Mach. No.	
			L				Ţ.	Do not require traceability.	Do not requ	Caps/Plugs	caps
					7.	"Lot Numbe	wed by "	Located on the bag followed by "Lot Number."	Located on	Snap Rings	Snap
				el.	ne box lab	d date on th	nber and	Use their work order number and date on the box label	Use their w	Flare Tubes	Flare
				1."	letter "N	ing with the	el, starti	Located on the spool label, starting with the letter "M."	Located on	Copper Tubing	Coppe
				eat."	word "he	y above the	, directly	Located on the box label, directly above the word "heat."	Located on	Brazing Rings	Brazin
				ity.	ox quant	abel under b	ne box la	Six digit no. located on the box label under box quantity.	Six digit no.	Flare Nuts	Flare
300 6066 T	E-RING					ımbers	blity Nu	Distinguishing Traceablity Numbers	Distingu		
A/N	ER15							2		Order Qty	Orde
No(s)	component(s)			S, LLC	devices, LLC	1		398031	39	Order No.	Orde
Heat Lot/Traceability	Component(c)	_		2	Contro			EXTO-X		. INC.	Part No.