									DO A ZINIO DODO I OTIONI DECODO	DD 471110 DD
							Meeting	6 (
	Or #63		Ö	77	V05.7	91-02	FAIR			
S	Notes	Inspector	Rev Letter	Yes / No Check	Эау	Submitted	Tooling	3 2 F		
		Inspection Record	First Part	11		H	Down Time Codes	-	Special Notes / Instructions	Specia
										ROUTING:
Z										
2	Z°+									
	ママイ									
	2.1									v
		4								
45 1	702-12-3/16+1csw-78-215	702-12-3	SCRAP 1	10		74	53	344-5 and	ZAC	1/26/11
Scrap Scrap Code		Notes		Down Time Code	Down Time	Cum. Total	Total Pcs.	rs.	Emp. Name	Date
No. of the last										
	Thru- put/8hrs		Pcs./Hr		Cycle	s.	Setup Hrs.	e e	Mach. No.	
	(3)	CP15					traceability.	Do not require traceability.	Caps/Plugs	Caps
		BRZ00			=	'Lot Number.	Located on the bag followed by "Lot Number."	ocated on the		Snap
		CSW-7/8-2.5	S		box label.	nd date on the	Use their work order number and date on the box label.	Use their work	Flare Tubes	Flare
		BRZ04			etter "M."	ting with the le	Located on the spool label, starting with the letter "M."	Located on the	Copper Tubing	Coppe
		JTU-17-3/16	CUT		ord "heat."	tly above the w	Located on the box label, directly above the word "heat."	Located on the	Brazing Rings	Brazir
		G3			x quantity.	label under bo	Six digit no. located on the box label under box quantity.	Six digit no. loca	Flare Nuts	Flan
		G-RING				lumbers	Distinguishing Traceablity Numbers	Distinguishi		
		702-12-3/16	70					50	Order Qty	Ord
12	No(s)	Component(s)	- 6	C	devices, LLC		9	397299	Order No.	Ord
oility	Heat Lot/Traceability				o to o		63-17F	S702123/163-17F	Part No.	Par