										6 Meeting			
				21000000000000000000000000000000000000	Check	Yes / No		Submitted		2 Tooling3 Setup			
	ž.	Notes	Inspector	Rev Letter	Mtrl	Approved	Time Of Day	Date Part					
			t Inspection Record	First Part I					Codes	Down Time Codes	tions	Special Notes / Instructions	Specia
													ROUTING:
	0												
	>												
													1
1	1	2											
)	125											
1													
											,	(111111111111111111111111111111111111111
0										J	2.	X	1.1.
Scrap	Scrap		Notes			Down Time Code	Down Time	Cum. Total	Cum	Total Pcs.	Prod Hrs.	Emp. Name	Date
		put/8hrs					Time		Hrs.			A	
		Thru-		Pcs./Hr			Cycle		Setup			Mach. No.	
									×	Do not require-traceability.	Do not requ	Caps/Plugs	Caps
							=	ot Number.	ed by "Lo	Located on the bag followed by "Lot Number."	ocated on		Snap
			CP13				box label.	date on the	ber and	Use their work order number and date on the box label	Jse their w	Flare Tubes	Flare
			BRZ22				etter "M."	g with the l	l, starting	Located on the spool label, starting with the letter "M."	ocated on	Copper Tubing	Coppe
			BRZ01				ord "heat."	above the w	directly a	Located on the box label, directly above the word "heat."	ocated on	Brazing Rings	Brazir
			CUTU-0-5/32	CU			x quantity.	el under bo	e box lab	Six digit no. located on the box label under box quantity.	Six digit no.	Flare Nuts	Flar
			CUTU-0-1/2	CI				bers	olity Num	Distinguishing Traceablity Numbers	Distingu		
			SF4-2.5-6	10			×			7		Order Qty	Ord
		No(s)	Component(s)	6		LLC	devices, LLC	H		390047	39	Order No.	Ord
	bility	Heat Lot/Traceability		?			ont no	ı		S4-2.5-6-24-B	54-2.	Part No.	Pal