

BRAZING PRODUCTION RECORD		Special N	ROUTING:								2/11/6	Date E	7	Caps/Plugs	Snap Rings	Flare Tubes	Copper Tubing	Brazing Rings	Flare Nuts		Order Qty	Order No.	
		Special Notes / Instructions									()	Emp. Name	Mach. No.			-	ubing				Qty	No.	
		tions										Prod Hrs.		Do not requ	Located on	Use their w	Located on	Located on	Six digit no	Disting		4(
	 Maintenance Tooling Setup FAIR Training Meeting 	Down Time Codes									Z Z	Total Pcs.		Do not require traceability.	Located on the bag followed by "Lot Number."	Use their work order number and date on the box label.	Located on the spool label, starting with the letter "M."	Located on the box label, directly above the word "heat."	Six digit no. located on the box label under box quantity.	Distinguishing Traceablity Numbers	10	400642	
		odes										Cum.	Setup Hrs.		ed by "Lot	ber and da	, starting	directly ak	box labe	lity Numb	la)	
	Submitted											Cum. Total			Number	ate on the	with the	ove the v	l under b	ers		A	
	Time Of Day											Down Time	Cycle Time		-	e box label.	letter "M."	word "heat."	ox quantity.			devices, LLC	1 1 1 1 1 1 1
	Approved Yes / No											Down Time Code										LLC	
	Mtrl Check														•	•							
	Rev Letter	First Part In					1						Pcs./Hr								11	Cor	
	Inspector	rt Inspection Record				7						Notes								C-RING	1102-18-1/4	Component(s)	(S) (S) (S)
), j	Ü.	(,				Thru- put/8hrs							2	503		- ווכמי בכ
	Notes																			P	NUX.	No(s)	THE COUNTY
				Þ		R5						Scrap									L		
												Scrap		Ç									