Notes	ter Inspection Record						Meeting	6 5		
	Inspector							1		
The state of the s	Inspector						FAIR	4		
The state of the s	Inspector						Setup	ω		
A SS A	spection Record	Rev Letter	Mtrl Check	Approved Yes / No	Time Of Day	Date Part Submitted	Maintenance Tooling	2 1		
A SS		First Part Ir					Down Time Codes	ctions	Special Notes / Instructions	Specia
A SS A										ROUTING:
A CO										
									മ	
							30		58	12/4
Scrap Scrap Code	Notes			Down Time Code	Down Time	Cum. Total	Total Pcs.	Prod Hrs.	Emp. Name	Date
put/8hrs		Pcs./Hr			Time	S.	Hrs.		Mach. No.	
Thru-					Cycle	- g	Setup			
							Do not require traceability.	Do not requir	Caps/Plugs	Caps
					· a	/"Lot Number	Located on the bag followed by "Lot Number."	Located on th	Snap Rings	Snap
					e box label.	nd date on th	Use their work order number and date on the box label.	Use their wor	Flare Tubes	Flare
	122				etter "M."	ting with the	Located on the spool label, starting with the letter "M."	Located on th	Copper Tubing	Coppe
					word "heat."	tly above the v	Located on the box label, directly above the word "heat."	Located on th	Brazing Rings	Brazir
					ox quantity.	label under b	Six digit no. located on the box label under box quantity.	Six digit no. Ic	Flare Nuts	Flan
20273300	A-RING					lumbers	Distinguishing Traceablity Numbers	Distinguis		
N/A	A40						0	30	Order Qty	Ord
No(s)	Component(s)	Con		LLC	devices, LLC	4	156	39275	Order No.	Ord
Heat Lot/Traceability	nonet(c)				on to o	ı)-R	A40-R	Part No.	Par