Test Form 11/4/15	Test Fo)RD	BRAZING PRODUCTION RECORD	BRAZING PRO
										6 Meeting			
		68		(7		*					
	CALL DELLA	10 M	本	1	9	UE2	PAR	1-22-21		3 Setup			
	tes	Notes	Inspector	Rev Letter	Mtrl Check	Approved Yes / No	Time Of Day	Date Part Submitted	nance	 Maintenance Tooling 			
			t Inspection Record	First Part Ir			B		Down Time Codes			Special Notes / Instructions	Specia
													ROUTING:
	7												
	?												
		,											
		Si											
		1											
		77											
		0 11											
					511							4	
													1
								55		35	35 mil	Y	12/30
Scrap Code	Scrap		Notes			Down Time Code	Down Time	Cum. Total		Total Pcs.	Prod Hrs.	Emp. Name	Date
		put/onits					11110		1113.				
		Thru-		Pcs./Hr			Cycle	J	Setup			Mach. No.	
									ability.	uire tracea	Do not require traceability.	Caps/Plugs	caps
								Located on the bag followed by "Lot Number."	ollowed by "	the bag fo	Located on		Snap
							box label.	Use their work order number and date on the box label.	number and	ork order	Use their w	_	Flare
							etter "M."	Located on the spool label, starting with the letter "M."	label, starti	the spool	Located on	σα	Coppe
			CP13				ord "heat."	Located on the box label, directly above the word "heat."	bel, directly	the box la	Located on	т_	Brazir
			BRZ03				x quantity.	Six digit no. located on the box label under box quantity.	in the box la	. located o	Six digit no	Flare Nuts	Flan
	ñ.		CUTU-1-1/2	CL				mbers	Distinguishing Traceablity Numbers	uishing Tra	Distingu		
	3	395369	F403-6-3/16	SF4	<u>J</u>					50		Order Qty	Ord
		No(s)	component(s)	Cor		LLC	devices, LLC	H		395369	39	Order No.	Ord
	ability	Heat Lot/Traceability					2	J		S403-6-3/16	\$403	Part No.	Par