Test Form 11/4/15	Test For										ORD	BRAZING PRODUCTION RECORD	BRAZING PRO
										5 Training6 Meeting			
			X (#03)		<	T/CS	12:40	2-8-16		4 FAIR			
	Notes		Inspector	Rev Letter	Check	Approved Yes / No	Time Of Day	Date Part Submitted	ance				
			nspection Record	First Part I		100			Down Time Codes			Special Notes / Instructions	Specia
													ROUTING:
	Z												
)												
											l		
					23								
		5.											
		4	7								l		
									\parallel				
									+				
							_						
							Ø	805	4	Hocs	Smico	370	11/8/16
Scrap Code	Scrap		Notes			Down Time Code	Down Time	Cum. Total		Total Pcs.	Prod Hrs.	Emp. Name	Date
を記る		put/8hrs					Time	Overline and the second	Hrs.			利を信息という。	
1		Thru-		Pcs./Hr			Cycle		Setup			Mach. No.	
									bility.	uire traceat	Do not require traceability.	Caps/Plugs	Caps
					4			Located on the bag followed by "Lot Number."	llowed by "	the bag fol	Located on	Snap Rings	Snap
					1		e box label.	Use their work order number and date on the box label	number and	ork order r	Use their w	Flare Tubes	Flare
							etter "M."	Located on the spool label, starting with the letter "M."	abel, starti	the spool I	Located on	Copper Tubing	Coppe
		7	CP13	70			vord "heat."	Located on the box label, directly above the word "heat."	bel, directly	the box lak	Located on	Brazing Rings	Brazir
		No.	BRZ23				ox quantity.	Six digit no. located on the box label under box quantity.	n the box la	. located or	Six digit no	Flare Nuts	Flare
		11/4	CUTU-1-1/2	CL				mbers	ceablity Nu	Distinguishing Traceablity Numbers	Disting		
			SF404-2-5/16	SF						3		Order Qty	Orde
	s)	No(s)	Component(s)	G.		LLC	devices, LLC	Ţ		399762	38	Order No.	Orde
	aceability	Heat Lot/Traceability))))			S404-2-5/16	\$404	Part No.	Par