										,		
			•						5 Training 6 Meeting			
												£.
				Check	Yes / No		Summitted		2 Tooling 3 Setup			
	Notes	Inspector	Rev Letter	Mtrl	Approved	Time Of Day	Date Part					
		First Part Inspection Record	First Part					Codes	Down Time Codes	ctions	Special Notes / Instructions	Specia
												ROUTING:
I												
?												
-		7										
+		7 8 7	5									
+										ı		
									_		86	3/9
Scrap Scrap	s	Notes			Down Time Code	Down Time	Cum. Total	Cur	Total Pcs.	Prod Hrs.	Emp. Name	Date
	Thru- put/8hrs		Pcs./Hr			Cycle Time		Setup Hrs.			Mach. No.	
	THE RESERVE THE PERSON NAMED IN COLUMN TWO IS NOT THE PERSON NAMED IN COLUMN TWO IS NAMED IN TRANSPORT TO THE PERSON NAMED IN TRAN	A THE RESERVE AND A STREET OF THE PARTY OF T	Section of the section of		WAS A COLUMN TO THE PERSON NAMED IN	Section of the last	April market programs	-	WALL SHARE SHARE SAVE	Application of the second		
								Ý	Do not require traceability.	Do not requ	Caps/Plugs	Caps
						=	ot Number.	/ed by "L	Located on the bag followed by "Lot Number."	Located on	Snap Rings	Snap
-						box label.	date on the	ber and	Use their work order number and date on the box label.	Use their w	Flare Tubes	Flare
						etter "M."	g with the l	el, startin	Located on the spool label, starting with the letter "M."	Located on	Copper Tubing	Coppe
				L		ord "heat."	above the w	directly	ocated on the box label, directly above the word "heat."	Located on	Brazing Rings	Brazir
	N/A	G-RING				x quantity.	oel under bo	e box lab	Six digit no. located on the box label under box quantity.	Six digit no.	Flare Nuts	Flare
	N/A	G10					nbers	olity Nun	Distinguishing Traceablity Numbers	Distingu		
	398956	702-8-1/4		l.					1		Order Qty	Orde
	No(s)	component(s)	6		TC	devices, LLC	H		399883	39	Order No.	Orde
	Heat Lot/Traceability		,			7			/02-8-1/4-10	702-0	Part No.	Par