Test Form 11/4/15	Te										ORD	BRAZING PRODUCTION RECORD	BRAZING PR
										6 Meeting			
					CIRCA	163/140		Control of the Contro		3 Setup			
	Notes		Inspector	Rev Letter	Mtrl	Approved	Time Of Day	Date Part	е				
			rt Inspection Record	First Part Ir					Codes	Down Time Codes	ctions	Special Notes / Instructions	Specia
													ROUTING:
	B												
	)												
		رار	C										
		7											
		3											
											1	1	
										ュ		SB	2/2
Scrap Code	Scrap	2	Notes			Down Time Code	Down Time	Cum. Total	C)	Total Pcs.	Prod Hrs.	Emp. Name	Date
		put/8hrs					Time		Hrs.				
		Thru-		Pcs./Hr			Cycle		Setup			Mach. No.	
									tv.	Do not require traceability.	Do not reau		Caps
							п	Lot Number.	wed by "I	Located on the bag followed by "Lot Number."	Located on	Snap Rings	Snap
							box label.	date on the	nber and	Use their work order number and date on the box label	Use their w	Flare Tubes	Flare
							etter "M."	ng with the l	el, startir	Located on the spool label, starting with the letter "M."	Located on	Copper Tubing	Coppe
îu.						ā	vord "heat."	above the w	, directly	Located on the box label, directly above the word "heat."	Located on	Brazing Rings	Brazir
							x quantity.	bel under bo	ne box la	Six digit no. located on the box label under box quantity.	Six digit no.	Flare Nuts	Flan
	NIA	Z	C-RING					mbers	blity Nur	Distinguishing Traceablity Numbers	Distingu		
	39346	393	1103-21-1/4	11	U.					14		Order Qty	Orde
	No(s)		Jomponent(s)	Con		LLC	devices, LLC	THE STATE OF THE S		399040	39	Order No.	Ord
	Heat Lot/Traceability	Heat Lo		}						1103-21-1/4-R	1103-	Part No.	Par