											Horizon Control	חומים המינים המינים המינים המינים	
										5 Training6 Meeting			
				_									
	S	Notes	Inspector	Rev Letter	Mtrl	Approved Yes / No	Time Of Day	Date Part Submitted		 Maintenance Tooling 			
			Inspection Record	First Part In						Down Time Codes	ctions	Special Notes / Instructions	Special
	Ó												ROUTING:
	3												
	?	,											
		Ch to											
		2											
		1											
										5		88	1/26
Scrap Code	Scrap	Ľ)	Notes			Down Time Code	Down Time	Cum. Total	Cum.	Total Pcs.	Prod Hrs.	Emp. Name	Date
		Thru- put/8hrs		Pcs./Hr			Cycle Time		Setup Hrs.			Mach. No.	
				the country of the country of the	The State of		Suchery Apple	Sola apprecia		Charles Carles Carles			1
										Do not require traceability.	Do not requ	Caps/Plugs	Caps,
								t Number.'	ed by "Lot	Located on the bag followed by "Lot Number."	Located on	Snap Rings	Snap
							box label.	ate on the	ber and d	Use their work order number and date on the box label.	Use their w	Flare Tubes	Flare
							etter "M."	with the le	, starting	Located on the spool label, starting with the letter "M."	Located on	Copper Tubing	Copper
							ord "heat."	bove the w	directly ak	Located on the box label, directly above the word "heat."	Located on	Brazing Rings	Brazin,
					•		x quantity.	l under bo	box labe	Six digit no. located on the box label under box quantity.	Six digit no.	Flare Nuts	Flare
		SOIHOTEL	J-RING					ers	lity Numb	Distinguishing Traceablity Numbers	Distingu		
		4/10	501-5-3/16	50						5		Order Qty	Orde
		No(s)	component(s)	COIL		LLC	devices, LLC	1.0 1.0		398163	39	Order No.	Orde
	ility	Heat Lot/Traceability	nonout(a)				200			501-5-3/16-R	501-5	Part No.	Part