												111111111111111111111111111111111111111
									Training Meeting	6 5		
										4 3		
	Notes	Inspector		Mtrl Check	Approved Yes / No	Time Of Day	Date Part Submitted	10	MaintenanceTooling	2 1		
		Inspection Record	First Part I					Codes	Down Time Codes	tions	Special Notes / Instructions	Specia
	K											ROUTING:
	2											
	1000											
	4 CC											
0000									نر		S.	16/
Scrap	Scrap	Notes			Down Time Code	Down Time	Cum. Total	5	Total Pcs.	Prod Hrs.	Emp. Name	Date
	put/8hrs	0				Time		Hrs.				
	Thru-		Pcs./Hr			Cycle		Setup			Mach. No.	
								ty.	Do not require traceability.	Do not requ	Caps/Plugs	Caps
						-	Lot Number	wed by "	Located on the bag followed by "Lot Number."	Located on		Snap
				L		box label.	date on the	nber and	Use their work order number and date on the box label.	Use their w	Flare Tubes	Flare
10						etter "M."	ng with the I	el, starti	Located on the spool label, starting with the letter "M."	Located on	Copper Tubing	Coppe
						vord "heat."	above the v	, directly	Located on the box label, directly above the word "heat."	Located on	Brazing Rings	Brazir
	N/A	A-KF004				ox quantity.	bel under bo	ne box la	Six digit no. located on the box label under box quantity.	Six digit no.	Flare Nuts	Flare
	N/N	DNC316-HT	D				mbers	ablity Nu	Distinguishing Traceablity Numbers	Distingu		
	194 JUSE	2203A-2-1/4-0	220						3		Order Qty	Ord
	No(s)	omponent(s)	Co		LLC	devices, LLC	H		397707	39	Order No.	Ord
	Heat Lot/Traceability								T/T-7-1000	2011		