										11		
									Training Meeting	6 5		
		(#03)			Š	disp	2-8-16			ω 4 ι		
Notes		Inspector	Rev Lette	d Mtrl Check	Approved Yes / No	Time Of Day	Date Part Submitted	ro		2		
	A SOLUTION STATES	t Inspection Record	First Part					Codes	Down Time Codes	tions	Special Notes / Instructions	Specia
												ROUTING:
Ť												
		J. J.										
		1155	1								1	
								_				
1												
*						7					1	1 11-
B						Ø	25	1	58	140 5 July	λ	2/8/11
Scrap		Notes		ī6	Down Time Code	Down Time	Cum. Total	Cui	Total Pcs.	Prod Hrs.	Emp. Name	Date
	back out o								The State of the S			
	Thru-		Pcs./Hr			Cycle Time		Setup Hrs.			Mach. No.	
				L				Ţ.	Do not require traceability.	Do not requ	Caps/Plugs	Caps
						=	ot Number.	wed by "l	Located on the bag followed by "Lot Number."	Located on t	Snap Rings	Snap
						box label.	date on the	nber and	Use their work order number and date on the box label.	Use their wo	Flare Tubes	Flare
	,					etter "M."	ng with the I	el, startir	Located on the spool label, starting with the letter "M."	Located on t	Copper Tubing	Coppe
	μ/A	BRZ08	-			vord "heat.	above the v	, directly	Located on the box label, directly above the word "heat."	Located on	Brazing Rings	Brazir
	N/A	CFT- 5/8				x quantity.	oel under bo	າe box lal	Six digit no. located on the box label under box quantity.	Six digit no.	Flare Nuts	Flan
		FLR-5/8					nbers	ablity Nur	Distinguishing Traceablity Numbers	Distingu		
	₩/A	SF5-3-8					1		50		Order Qty	Ord
<u>.</u>	No(s)	component(s)	6		LLC	devices, LLC	Ŧ		399775	39	Order No.	Ord
ceability	Heat Lot/Traceability		2			ont not	l		15-3-8	7.7	Part No.	Par