Test Form 11/4/15	Test										ORD	BRAZING PRODUCTION RECORD	BRAZING PRO
									44 25	6 Meeting			
									Maria de la companya				
					Check	Yes / No		Submitted		3 Setup			
	Notes		Inspector	-	_		Time Of Day	Date Part	nance				
			Inspection Record	First Part Ir					Down Time Codes	Down T	ctions	Special Notes / Instructions	Specia
													ROUTING:
	3								-				
			Ð				griff a						
									-				
		5											
)											
													L
													8
									+				
									-				1
										ىد		SS	1/25
Scrap Code	Scrap		Notes		<u> </u>	Down Time Code	Down Time	Cum. Total		Total Pcs.	Prod Hrs.	Emp. Name	Date
		but/ours	CONTROL STORY STORY STORY				-		-				
		Thru-		Pcs./Hr			Cycle	ō	Setup			Mach. No.	
									S. D. D. C. D. C.	A SOLUTION S			
									bility.	Do not require traceability.	Do not req	Caps/Plugs	Caps
							. =	Located on the bag followed by "Lot Number."	ollowed by	the bag fo	Located on	Snap Rings	Snap
							box label.	Use their work order number and date on the box label.	number an	ork order	Use their w	Flare Tubes	Flare
							etter "M."	Located on the spool label, starting with the letter "M."	label, start	the spool	Located on	Copper Tubing	Coppe
						-	vord "heat."	Located on the box label, directly above the word "heat."	bel, directl	the box la	Located on	Brazing Rings	Brazir
o jeropiene	0667	30060667	E-RING		I		ox quantity.	Six digit no. located on the box label under box quantity.	n the box l	. located o	Six digit no	Flare Nuts	Flare
	A	NIA	E4					ımbers	Distinguishing Traceablity Numbers	uishing Tra	Disting		
	A	NIN	901-9-1/4	9	Į.					2		Order Qty	Orde
	No(s)	No	components			LLC	devices, LLC	The state of the s		398025	3:	Order No.	Ord
	Heat Lot/Traceability	Heat Lot/1	apapan+(s)	Ç.			ontrol			901-9-1/4-4	901.	Part No.	Par