		THE REAL PROPERTY.	S. California de				A	6 Meeting			
		MX		AS.	6:25	2:23-/6	8		***************************************		
	Notes	Inspector	Mtrl Check Rev Letter	Approved Yes / No C	Time Of Day	Date Part Submitted	ance	 Maintenance Tooling 			
		rt Inspection Record	First Part	Section 19 Section			Down Time Codes	Down Ti	tions	Special Notes / Instructions	Specia
											ROUTING:
*	+										
	\ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \	9									
	200										
										8-	
							+				
					7				10.50.1	-	, ,,,
					0	V		S		y C	2/23/11
Scrap Scrap	Sc	Notes		Down Time Code	Down Time	Cum. Total		Total Pcs	Prod Hrs.	Emp. Name	Date
	put/8hrs				Time		Hrs.				
	Thru-		Pcs./Hr		Cycle	- G	Setup			Mach. No.	
							bility.	uire traceal	Do not require traceability.	Caps/Plugs	Caps
					•=	Located on the bag followed by "Lot Number."	llowed by	the bag fo	Located on	Snap Rings	Snap
					e box label.	Use their work order number and date on the box label	number ar	ork order r	Use their w	Flare Tubes	Flare
					etter "M."	Located on the spool label, starting with the letter "M."	label, start	the spool I	Located on	Copper Tubing	Coppe
		CP13			vord "heat."	Located on the box label, directly above the word "heat."	bel, direct	the box lab	Located on	Brazing Rings	Brazir
_	134625	BRZ23			ox quantity.	Six digit no. located on the box label under box quantity.	n the box l	located or	Six digit no.	Flare Nuts	Flan
か の の	88 V//V	CUTU-1-1/2	0			umbers	ceablity N	Distinguishing Traceablity Numbers	Distingu		
	11/0	SF403-2-1/4	S					10		Order Qty	Ord
	No(s)	Component(s)	- 6	TC	devices, LLC	A		401411	40	Order No.	Ord
	Heat Lot/Traceability)					S403-2-1/4	\$40	Part No.	Par