								Meeting			
								FAIR Training	4 7		
			7	+	103/10			Setup	3 1		
	Notes	Inspector		ed Mtrl	, Approved	Time Of Day	Date Part Submitted	Maintenance Tooling	1 2		
		First Part Inspection Record	First Part I					Down Time Codes	tions	Special Notes / Instructions	Specia
											ROUTING:
,	t										
										63	
	1.502										
	1,5										
	5										
								30		98	2/2
1	Scrap	Notes			1	Down Time	Cum. Total	Total Pcs.	Prod Hrs.	Emp. Name	Date
Scrap				me .	Down Time						
	Thru- put/8hrs		Pcs./Hr			Cycle Time	s.	Setup Hrs.		Mach. No.	
	18.							Do not require traceability.	Do not requi	Caps/Plugs	Cap
							y "Lot Number	Located on the bag followed by "Lot Number."	Located on t	Snap Rings	Snaj
						e box label.	ind date on th	Use their work order number and date on the box label.	Use their wo	Flare Tubes	Flare
¥.						letter "M."	rting with the	Located on the spool label, starting with the letter "M."	Located on t	Copper Tubing	Coppe
						word "heat.	tly above the	Located on the box label, directly above the word "heat."	Located on tl	Brazing Rings	Brazii
					*	ox quantity	label under b	Six digit no. located on the box label under box quantity.	Six digit no. l	Flare Nuts	Flar
	20151504	G-RING					lumbers	Distinguishing Traceablity Numbers	Distinguis		
	N/A	G4						0	20	Order Qty	Ord
	No(s)	Component(s)	2		LLC	devices, LLC	÷	270	392270	Order No.	Ord
	Heat Lot/Traceability	nnonent(c)	2			Control		G4-K	94	Part No.	Pai