Test Form 11/4/15	Test)RD	BRAZING PRODUCTION RECORD	BRAZING PRO
										5 Training6 Meeting			
	Notes		Inspector	Rev Letter	Mtrl	Approved Yes / No	Time Of Day	Date Part Submitted	nce	 Maintenance Tooling 			
			t Inspection Record	First Part In					ne Codes			Special Notes / Instructions	Specia
													ROUTING:
	Z												
)												
		7.7	P										
		ν.	0.										
		4	2										
		0											
				15									
										نى		SB	3/8
Scrap	Scrap		Notes			Down Time Code	Down Time	Cum. Total	Q	Total Pcs.	Prod Hrs.	Emp. Name	Date
		put/8hrs					Time		Hrs.				
	ACTUAL OF THE PROPERTY OF THE PERSON	Thru-		Pcs./Hr			Cycle	70	Setup			Mach. No.	
									ility.	Do not require traceability.	Do not requ	Caps/Plugs	Caps
							Ē	Located on the bag followed by "Lot Number."	owed by '	the bag foll	Located on	Snap Rings	Snap
							e box label.	Use their work order number and date on the box label.	umber an	ork order nu	Use their w	Flare Tubes	Flare
							etter "M."	Located on the spool label, starting with the letter "M."	bel, start	the spool la	Located on	Copper Tubing	Coppe
						-	vord "heat."	Located on the box label, directly above the word "heat."	el, directi	the box lab	Located on	Brazing Rings	Brazii
	30060667	38	E-RING				ox quantity.	Six digit no. located on the box label under box quantity.	the box la	. located on	Six digit no.	Flare Nuts	Flar
	NA		ER8					ımbers	eablity Nu	Distinguishing Traceablity Numbers	Distingu		
	399701	نر	3-16-3/16-5/8	903-1						3		Order Qty	Ord
	No(s)		Component(s)	Con		ררכ	devices, LLC	H		399745	35	Order No.	Ord
	Heat Lot/Traceability	Heat Lo								903-16-3/165/88	903-16	Part No.	Pai