Test Form 11/4/15	Test Fo										ORD	BRAZING PRODUCTION RECORD	BRAZING PR
										6 Meeting			
			9			1							
		,	7/ 100		SIG	705	12:30	3-23-16					
	S	Notes	Inspector CD	Rev Letter	Mtrl Check	Approved Yes / No	Time Of Day	Date Part Submitted	(1)	<ol> <li>Maintenance</li> <li>Tooling</li> </ol>			
			Inspection Record	First Part Ir					Codes	Down Time Codes	ctions	Special Notes / Instructions	Specia
	4												ROUTING:
	5												
	Ī												
		000											
		5000	(										
		NI TE	1										
		0 1 /	1										
			\ F!\\ \\										
			100										
		31											
						+				2			
										7/2			
			9	3	,			300	w	200	Z,	STZ .	3/23/16
Scrap	Scrap		Notes			Down Time Code	Down Time	Cum. Total	C)	Total Pcs.	Prod Hrs.	Emp. Name	Date
		put/8hrs					Time		Hrs.				
		Thru-		Pcs./Hr			Cycle	_ ~	Setup			Mach. No.	
		Œ	CP13						ty.	Do not require traceability.	Do not requ	Caps/Plugs	Caps
			L-RING				п	_ot Number.	ved by "I	Located on the bag followed by "Lot Number."	Located on	Snap Rings	Snap
			BRZ23				box label.	date on the	nber and	Use their work order number and date on the box label.	Use their w	Flare Tubes	Flare
			CUTU-1.875-1/2	CUTI			etter "M."	ng with the l	el, startir	Located on the spool label, starting with the letter "M."	Located on	Copper Tubing	Coppe
		·	BRZ04		I		ord "heat."	above the w	, directly	Located on the box label, directly above the word "heat."	Located on	Brazing Rings	Brazir
			UTU-17-3/16	CUT			x quantity.	bel under bo	າe box lal	Six digit no. located on the box label under box quantity.	Six digit no.	Flare Nuts	Flan
			L1-1/2					nbers	blity Nur	Distinguishing Traceablity Numbers	Disting		
			SF403-4-3/16	SF4						300	22.50	Order Qty	Ord
		No(s)	omponent(s)	- Co		LLC	devices, LLC	C C		404187	40	Order No.	Ord
	yility	Heat Lot/Traceability		?			1			S40343-161.517F	S40343	Part No.	Par