lest Form 11/4/15	est										ORD	BRAZING PRODUCTION RECORD	BRAZING PF
	1								ď	н			
									16 18	6 Meeting			
									i				
									(9				
		Notes	Inspector	Rev Letter	Mtrl Check	Approved Yes / No	Time Of Day	Date Part Submitted	Maintenance Tooling	 Mainter Tooling 			
			First Part Inspection Record	First Part In					Down Time Codes	Down	ictions	Special Notes / Instructions	Speci
													ROUTING:
	Ò												
	P												
											1		
		1	5										
),					1						
		1	5										
E	0.00	5								+			
		S											
										ō		SB	12/15
Scrap Code	Scrap		Notes			Down Time Code	Down Time	Cum. Total		Total Pcs.	Prod Hrs.	Emp. Name	Date
		put/anrs					Time		Hrs.				
		Thru-		Pcs./Hr			Cycle		Setup			Mach. No.	
						TO DESCRIPTION OF THE PERSON O			ability.	Do not require traceability.	Do not rev	Caps/Plugs	Cap
								Located on the bag followed by "Lot Number."	followed by "	n the bag f	Located o		Snai
		5					box label.	Use their work order number and date on the box label.	number and	work order	Use their	Flare Tubes	Flare
							etter "M."	Located on the spool label, starting with the letter "M."	I label, startii	n the spoo	Located o	Copper Tubing	Coppe
							ord "heat."	Located on the box label, directly above the word "heat."	abel, directly	n the box I	Located o	Brazing Rings	Brazii
							x quantity.	Six digit no. located on the box label under box quantity.	on the box la	o. located ι	Six digit no	Flare Nuts	Flar
		20060667	E-RING	ψ.				nbers	Distinguishing Traceablity Numbers	guishing Tr	Disting		
		N/A	E10							10		Order Qty	Ord
		No(s)	Component(s)	Com		LC	devices, LLC	1 C		393906	w	Order No.	Ord
	ity	Heat Lot/Traceability	nonent(s)	Com			On tool			E10-R		Part No.	Pai