	(Meeting	6		
	Or NO		A		1			Training	5 4		
	0000	N.		9	467	84~	2-15-16	Setup	<u>ν</u> ω		
	Notes	Inspector		Mtrl Check	Approved Yes / No	Time Of Day	Date Part Submitted	Maintenance Tooling	2		
	The same of the sa	First Part Inspection Record	First Part I					Down Time Codes		Special Notes / Instructions	Special I
ć											ROUTING:
1	(
>	355										
	1777										
											53
			a <mark>.</mark>								
G						0	11865	Hoas	1410 25 att	C	2/15/16
Scrap	-	Notes	.jn		Down Time Code	Down Time	Cum. Total	Total Pcs.	Prod Hrs.	Emp. Name	Date
	10 mg			S. Name (Name)	The second second	Angeography			がまたします	建设是国家的	
· 大	Thru-		Pcs./Hr			Cycle	Setup Hrs.	Se		Mach. No.	
								Do not require traceability.	Do not requ		Caps/Plugs
						=	y "Lot Number	Located on the bag followed by "Lot Number."	Located on		Snap Rings
		CP13				e box label.	and date on th	Use their work order number and date on the box label.	Use their wo	Flare Tubes	Flare
		BRZ22				letter "M."	arting with the	Located on the spool label, starting with the letter "M."	Located on	σq	Copper
	19/11	BRZ01			=	word "heat.	ctly above the	Located on the box label, directly above the word "heat."	Located on		Brazin
	A	CUTU-24-5/32	C		•	ox quantity	x label under b	Six digit no. located on the box label under box quantity.	Six digit no.	Flare Nuts	Flare
	2//2	CSW-3-1/2					Numbers	Distinguishing Traceablity Numbers	Distingu		
	N/A	SF4-2.5-6						6		Order Qty	Orde
Ly	No(s)	Component(s)	6		ררכ	devices, LLC	Ŧ	400167	40	Order No.	Orde
# *	Heat Lot/Traceah		_			1					