BRAZING PRO		Specia	ROUTING:					-	1/19/10	Date		Caps	Snap	Flare	Coppe	Brazir	Flare		Orde	Ord	Par
BRAZING PRODUCTION RECORD		Special Notes / Instructions							YO	Emp. Name	Mach. No.	Caps/Plugs	Snap Rings	Flare Tubes	Copper Tubing	Brazing Rings	Flare Nuts		Order Qty	Order No.	Part No.
ORD	654321	ictions				2		24 min	State of the state	Prod Hrs.		Do not requ	Located on	Use their w	Located on	Located on	Six digit no.	Distingu		39	S704-
	SEC. NO. 10 TO ASSESS OF THE PARTY OF THE PA	Down Time Codes						-	4	Total Pcs.		Do not require traceability.	Located on the bag followed by "Lot Number."	Use their work order number and date on the box label.	Located on the spool label, starting with the letter "M."	Located on the box label, directly above the word "heat."	Six digit no. located on the box label under box quantity.	Distinguishing Traceablity Numbers	HA	397357	S704-20-3/16
		Codes						-	H	Cum. Total	Setup Hrs.	ļ	ved by "Lot N	nber and dat	el, starting w	directly abo	ıe box label ι	blity Numbe		_	
	Date Part Submitted T L/G-/												Number."	e on the b	ith the let	ve the wo	ınder box	rs			
	Time Of Day							į	Q	Down Time	Cycle Time			ox label.	ter "M."	ord "heat."	quantity.			devices, LLC	1
	Approved Yes / No									Down Time Code										TC	
	Mtrl Rev	Firs									P					Т			ī		7
	Rev Letter	t Part Inspe									Pcs./Hr					C.	BR	CUTU	SF704-	Compo	V0000000000000000000000000000000000000
	Inspector	First Part Inspection Record								Notes						CP15	BRZ09	CUTU-1-7/8	SF704-20-3/16	Component(s)	The state of the s
	(3)						*				Thru- put/8hrs								ž		Heat I
	Notes			55								*							1251	No(s)	Heat Lot/Traceability
Test			2	\$					0	Scrap									1		oility
Test Form 11/4/15										Scrap											