										j	100000000000000000000000000000000000000	1
									6 Meeting			
	Notes	Inspector	Rev Letter	Mtrl Check	Approved Yes / No	Time Of Day	Date Part Submitted	i.i	 Maintenance Tooling Setun 			
A TOWNSON	A THE STATE OF THE PARTY OF THE	t Inspection Record	First Part					Codes	Down Time Codes	tions	Special Notes / Instructions	Specia
												ROUTING:
0												
2												
		2										
		-										
		1200										
		70										
	2/4	2										
									Ţ		SB	2/35
Scrap Scrap		Notes			Down Time Code	Down Time	Cum. Total	Cun	Total Pcs.	Prod Hrs.	Emp. Name	Date
	put/8hrs		1, 1,00			Time	8	Hrs.				
	Thru-		Pcs./Hr			Cycle		Setup			Mach. No.	
				_				, Y	Do not require traceability.	Do not requ	Caps/Plugs	Caps
							ot Number.	ved by "L	Located on the bag followed by "Lot Number."	Located on	Snap Rings	Snap
						box label.	date on the	nber and	Use their work order number and date on the box label.	Use their w	Flare Tubes	Flare
						etter "M."	g with the le	રો, startin	Located on the spool label, starting with the letter "M."	Located on	Copper Tubing	Coppe
						ord "heat."	above the w	directly a	Located on the box label, directly above the word "heat."	Located on	Brazing Rings	Brazir
	N/N	A-KF004				x quantity.	el under bo	e box lab	Six digit no. located on the box label under box quantity.	Six digit no.	Flare Nuts	Flare
	N/A	DCN316-HT	D				bers	blity Num	Distinguishing Traceablity Numbers	Distingu		
	£77.004	2203A-9-1/4-0	220						4		Order Qty	Orde
	No(s)	component(s)	CO		LC	devices, LLC			401836	40	Order No.	Orde
_	Heat Lot/Traceability	monost(c)	2			On tool	ı		2203A-9-1/4	2203	Part No.	Par