Test Form 11/4/15	Test Fo										ORD	BRAZING PRODUCTION RECORD	BRAZING PRO
										6 Meeting			
		Notes	Inspector		Mtrl Check	Approved Yes / No	Time Of Day	Date Part Submitted	тсе	<ol> <li>Maintenance</li> <li>Tooling</li> <li>Setur</li> </ol>			
			Inspection Record	First Part In					ne Codes	Down Time	ctions	Special Notes / Instructions	Specia
	3												ROUTING:
	P												
			7										
		5	7-1										
		2											
										Ui.		56	3/19
Scrap Code	Scrap		Notes			Down Time Code	Down Time	Cum. Total	Cr	Total Pcs.	Prod Hrs.	Emp. Name	Date
が記せ		put/8hrs					Time		Hrs.				
		Thru-		Pcs./Hr			Cycle	5	Setup			Mach. No.	
	L								ility.	Do not require traceability.	Do not requ	Caps/Plugs	Caps
							i a	Located on the bag followed by "Lot Number."	owed by "	the bag foll	Located on		Snap
							box label.	Use their work order number and date on the box label.	umber and	ork order nu	Use their w	Flare Tubes	Flare
							etter "M."	Located on the spool label, starting with the letter "M."	bel, starti	the spool la	Located on	Copper Tubing	Coppe
							vord "heat."	Located on the box label, directly above the word "heat."	el, directly	the box lab	Located on	Brazing Rings	Brazir
							ox quantity.	Six digit no. located on the box label under box quantity.	the box la	. located on	Six digit no.	Flare Nuts	Flan
		9 "	C-RING					mbers	eablity Nu	Distinguishing Traceablity Numbers	Distingu		
		401305	CR20							5		Order Qty	Orde
***		No(s)	Component(s)	Con		ררכ	devices, LLC	THE STATE OF THE S		401304	40	Order No.	Ord
	lity	Heat Lot/Traceability	A10.6.5	)			· · · · · · · · · · · · · · · · · · ·			CR20-R	CF	Part No.	Par