										5 Training 6 Meeting			
				_1_									
	~	Notes	Inspector	Rev Lett	d Mtrl Check	Approved Yes / No	Time Of Day	Date Part Submitted	nce	<ol> <li>Maintenance</li> <li>Tooling</li> </ol>			
			t Inspection Record	First Part I	200				ne Codes	Down Time	tions	Special Notes / Instructions	Specia
													ROUTING:
	S												
	R		+		1								
		1,5											
		5											
										ō		SB	12/17
Scrap Code	Scrap		Notes		O	Down Time Code	Down Time	Cum. Total	0	Total Pcs.	Prod Hrs.	Emp. Name	Date
		put/8nrs					IIme		Hrs.				
		Thru-		Pcs./Hr			Cycle	ס	Setup			Mach. No.	
					L				ility.	Do not require traceability.	Do not requ	Caps/Plugs	Caps
							· a	Located on the bag followed by "Lot Number."	owed by	the bag foll	ocated on		Snap
							box label.	Use their work order number and date on the box label.	umber an	ork order nu	Jse their w	Flare Tubes	Flare
							etter "M."	Located on the spool label, starting with the letter "M."	ibel, start	the spool la	ocated on	Copper Tubing	Coppe
						-	vord "heat."	Located on the box label, directly above the word "heat."	el, directl	the box lab	ocated on	Brazing Rings	Brazin
							ox quantity.	Six digit no. located on the box label under box quantity.	the box la	located on	ix digit no.	Flare Nuts	Flare
		99Loh10E	J-RING		_			ımbers	eablity Nu	Distinguishing Traceablity Numbers	Distingu		
		NIA	501-6-3/16	50			8			10		Order Qty	Orde
		No(s)	component(s)	·		LLC	devices, LLC	THE STATE OF THE S		394464	39	Order No.	Orde
	ility	Heat Lot/Traceability					200			201-0-1/C-V	D-TOC	דמונ ואט.	FdI