							Meeting	6 (
							FAIR			
	(Application and any of			Yes / No Check	_	Submitted	Setup Setup			
	Notes	Inspector	Rev Lett	-	Time Of Day Ap		Maintenance	1		
		rt Inspection Record	First Part				Down Time Codes	tions	Special Notes / Instructions	Specia
										ROUTING:
	T									
			10							
		-								
	55	J. J.								
		ハノレ								
	7									
	5						_			
							Q		(
0000)		- /	2
Scrap	Scrap	Notes		Down Time Code	Down Time Do	Cum. Total	Total Pcs. Cu	Prod Hrs.	Emp. Name	Date
A STATE OF THE PARTY OF THE PAR	put/8hrs				lime		Hrs.			
	Thru-	~	Pcs./Hr		Cycle		Setup		Mach. No.	
							traceability.	Do not require traceability.	Caps/Plugs [Cap
						Lot Number.'	Located on the bag followed by "Lot Number."	ocated on the		Snaj
					box label.	d date on the	Use their work order number and date on the box label.	Jse their work	Flare Tubes	Flare
,					etter "M."	ng with the le	Located on the spool label, starting with the letter "M."	ocated on the	Copper Tubing	Coppe
7			74		ord "heat."	above the w	Located on the box label, directly above the word "heat."	ocated on the	Brazing Rings	Brazii
					x quantity.	bel under bo	Six digit no. located on the box label under box quantity.	six digit no. lo	Flare Nuts	Flar
\	を一方	G-RING				mbers	Distinguishing Traceablity Numbers	Distinguish		
	3819X	701-6-3/16						12	Order Qty	Ord
	No(s)	Component(s)			devices, LLC		49	400649	Order No.	Ord
	Heat Lot/Traceability		,		7	ı	/16-R	/UI-6-3/16-K	Part No.	Pai