											6 5		
				Þ							2 2		
	es.	Notes	Inspector	Rev Letter	Mtrl Check	Approved Yes / No	Time Of Day	Date Part Submitted			2 1		
			t Inspection Record	First Part I					Codes	Down Time Codes	tions	Special Notes / Instructions	Specia
													ROUTING:
	7												
)		1										
		57	V										
		3	5										
		72											
								<u> </u>					
		.1											2-
		STOCK	Toom	03770	t					_			11/0
Scrap Code	Scrap		Notes			Down Time Code	Down Time	Cum. Total	Cun	Total Pcs.	Prod Hrs.	Emp. Name	Date
		put/8nrs					IIIIe		1113.				
		Thru-		Pcs./Hr			Cycle		Setup			Mach. No.	
	L									A COLUMN A STATE OF THE STATE O			
									Υ.	Do not require traceability.	Do not regu		Caps
							-	ot Number.	ed by "L	Located on the bag followed by "Lot Number."	Located on t	Snap Rings	Snap
			CP15				box label.	date on the	ber and	Use their work order number and date on the box label.	Use their wo	Flare Tubes	Flare
			CUTU-0-7/8	CL			etter "M."	g with the k	el, startin	Located on the spool label, starting with the letter "M."	Located on t	Copper Tubing	Coppe
			BRZ05			Cas	ord "heat."	above the w	directly a	Located on the box label, directly above the word "heat."	Located on t	Brazing Rings	Brazir
			BRZ09				x quantity.	el under bo	e box lab	Six digit no. located on the box label under box quantity.	Six digit no.	Flare Nuts	Flan
			CUTU-0-1/4	CL				nbers	olity Num	Distinguishing Traceablity Numbers	Distingu		
			7-4-9	-CE						1		Order Qty	Ord
	22	No(s)	Lomponent(s)	6		ררכ	devices, LLC	H		393203	39:	Order No.	Ord
	bility	Heat Lot/Traceability)						5/-4-9-24-C	3/-4-	Part No.	Par