Test Form 11/4/15	Tes										CORD	BRAZING PRODUCTION RECORD	BRAZING PR
				_					Meeting	2000			
			Hat.	75	,	0	0		FAIR Training				
			2	d	_	R	1	2-161	Setup				
	Notes		Inspector	Rev Letter	o Check	Approved Yes & No	Time Of Day	Date Part Submitted	Maintenance Tooling	1 Ma 2 To			
27			Inspection Record	First Part In					Down Time Codes	Do	ructions	Special Notes / Instructions	Specia
													ROUTING:
	7									*			
		<											
	Ş	)											
	60									+			
	2												
	3								-	+			
							,						/
							0	06	O O			30	3/16/16
Scrap Code	Scrap		Notes		ne	Down Time Code	Down Time	Cum. Total	Total Pcs.		Prod Hrs.	Emp. Name	Date /
		put/8hrs		# C 100 m m m m m m m m m m m m m m m m m m			Time	·s.	Hrs.				
		Thru-		Pcs./Hr			Cycle	g	Setup			Mach. No.	
6)									aceability.	Do not require traceability.	Do no	Caps/Plugs	Cap
							• =	Located on the bag followed by "Lot Number."	ag followed b	ed on the b	Locate	Snap Rings	Sna
9110 11					li I		e box label.	Use their work order number and date on the box label.	rder number a	heir work o	Use th	Flare Tubes	Flan
							etter "M."	Located on the spool label, starting with the letter "M."	pool label, sta	ed on the s	Locate	Copper Tubing	Coppe
			CP13				word "heat.	Located on the box label, directly above the word "heat."	ox label, dired	ed on the b	Locate	<b>Brazing Rings</b>	Brazi
			BRZ23			• 42.7	ox quantity	Six digit no. located on the box label under box quantity.	ed on the box	git no. loca	Six dig	Flare Nuts	Flar
			CUTU-1-1/2	5	Ш			lumbers	Distinguishing Traceablity Numbers	istinguishin	Di.		
111/0			SF405-5-1/4-1/2	SF40						17		Order Qty	Ord
	No(s)		Component(s)	Cor		LLC	devices, LLC	H		402869		Order No.	Orc
	Heat Lot/Traceability	Heat Lo					7		-1/2	S405-5-1/4-1/2	10	Part No.	Pa