Test Form 11/4/15	Test F										ORD	BRAZING PRODUCTION RECORD	BRAZING PRO
				A						4 FAIR 5 Training			
				>									
		Notes	Inspector	Rev Letter	Mtrl	Approved Yes / No	Time Of Day	Date Part Submitted	Ф	<ol> <li>Maintenance</li> <li>Tooling</li> </ol>			
			Inspection Record	First Part In					Codes	Down Time	ctions	Special Notes / Instructions	Specia
													ROUTING:
	T												
	?												
		52.4											
		5-											
	8		19	NEW PART	Z	W	30			30	1 MR 4/Som	40	11/11
Scrap Code	Scrap		Notes			Down Time Code	Down Time	Cum. Total	5	Total Pcs.	Prod Hrs.	Emp. Name	Date
							The second second	上 一 一 一 一 一 一 一 一 一 一 一 一 一 一 一 一 一 一 一	Sept Special		No. of the last of		
		Thru- put/8hrs		Pcs./Hr			Cycle Time		Setup Hrs.			Mach. No.	
		4							ty.	Do not require traceability.	Do not requ	Caps/Plugs	Caps
							=	Lot Number.	ved by "I	Located on the bag followed by "Lot Number."	Located on	Snap Rings	Snap
							box label.	date on the	nber and	Use their work order number and date on the box label.	Use their w	Flare Tubes	Flare
					1		etter "M."	ng with the le	el, startir	Located on the spool label, starting with the letter "M."	Located on	Copper Tubing	Copper
			FLR-5/8	-			ord "heat."	above the w	directly	Located on the box label, directly above the word "heat."	Located on	Brazing Rings	Brazin
			CFT-5/8	0	I		x quantity.	bel under bo	ne box la	Six digit no. located on the box label under box quantity.	Six digit no.	Flare Nuts	Flare
			BRZ07					mbers	blity Nur	Distinguishing Traceablity Numbers	Distingu		
			502-5-1/4	5(						20	33	Order Qty	Orde
		No(s)	component(s)	Coll		ררכ	devices, LLC	1		390155	39	Order No.	Orde
	ty	Heat Lot/Traceability	popont(s)				ont rol			F502-5-1/4	F502	Part No.	Pan