									ı			
									Training Meeting	6 5		
										4 3		
Notes		Inspector	Rev Letter	Mtrl Check	Approved Yes / No	Time Of Day	Date Part Submitted	2.5		2 1		
		First Part Inspection Record	First Part In:					Codes	Down Time Codes	tions	Special Notes / Instructions	Specia
ð												ROUTING:
7												
1	1											
1	3											
~												
5												
	1											
									30		ò	1,30
				Ī	cour				,		Ŝ	100
Scrap		Notes			Down Time	Down Time	Cum. Total	Cur	Total Pcs.	Prod Hrs.	Emp. Name	Date
rs	put/8hrs		1 007111			Time		Hrs.				
Company of the Compan	Thru-		Doc /Hr			Cycle		Setup			Mach, No.	
				_				, Y	Do not require traceability.	Do not requ	Caps/Plugs	Caps
						î e	ot Number	ved by "L	Located on the bag followed by "Lot Number."	Located on		Snap
						box label.	date on the	nber and	Use their work order number and date on the box label.	Use their wo	Flare Tubes	Flare
				-		etter "M."	g with the I	el, startin	Located on the spool label, starting with the letter "M."	located on	Copper Tubing	Coppe
						vord "heat."	above the v	directly	Located on the box label, directly above the word "heat."	Located on	Brazing Rings	Brazir
						ox quantity.	el under bo	e box lak	Six digit no. located on the box label under box quantity.	Six digit no.	Flare Nuts	Flan
20140766	20	J-RING		2			nbers	blity Nun	Distinguishing Traceablity Numbers	Distingu		
71807	60	502-6-1/4	50						30		Order Qty	Ord
No(s)		component(s)	Com		LLC	devices, LLC	F.		391810	39	Order No.	Ord
near Lot/ traceability	1100	nonon+(c)				Cotto	Anna man	_	2 - 1 - 1 - 1 - 1 - 1 - 1 - 1 - 1 - 1 -			