	ROUTING:	Date Emp. Name	Mach. No.	Flare Nuts Brazing Rings Copper Tubing Flare Tubes Snap Rings Caps/Plugs	Order Qty
6 5 4 3 2 1		Prod Hrs. To		Distinguishing Traceability Numbers Six digit no. located on the box label under box quantity. Located on the box label, directly above the word "heat." Located on the spool label, starting with the letter "M." Use their work order number and date on the box label. Located on the bag followed by "Lot Number." Do not require traceability.	9
Maintenance Tooling Setup FAIR Training Meeting		Total Pcs.	Se H	Distinguishing Traceability Numbers digit no. located on the box label unated on the box label, directly above ated on the spool label, starting with their work order number and date ated on the bag followed by "Lot Nunot require traceability.	9
Date Part Submitted		Cum. Total	Setup Hrs.	Numbers x label under b ctly above the arting with the and date on th y "Lot Number	
Time Of Day 9:50		Down Time	Cycle Time	ox quantity. word "heat." letter "M." e box label.	
Approved Mtri Yes / No Check YES OL		Down Time Code			
Rev Lette			Pcs./Hr	CI CI	S
er Inspector		Notes		CUTU-3-1/2 :UTU-24-5/32 BRZ01 BRZ22 CP13	SF4-2.5-6
	35.25		Thru- put/8hrs		36.25
Notes		Sc			3813
		Scrap Scrap Code			