											and the second		
										5 Training 6 Meeting			
	Notes		Inspector	Rev Letter	Mtrl Check	Approved Yes / No	Time Of Day	Date Part Submitted		 Maintenance Tooling 			
			irst Part Inspection Record	First Part Ir				1814	Codes	Down Time Codes	ctions	Special Notes / Instructions	Special
	1										111		ROUTING:
	9												
				ı		1							
		~											
	3	1301											
		2											
	1												
	-												
										30		98	12/2
Scrap Code	Scrap		Notes			Down Time Code	Down Time	Cum. Total	Cun	Total Pcs.	Prod Hrs.	Emp. Name	Date
		Thru- put/8hrs		Pcs./Hr			Cycle Time		Setup Hrs.			Mach. No.	
	3								, X	Do not require traceability.	Do not requ	Caps/Plugs	Caps/
							=	ot Number.	ved by "Lo	Located on the bag followed by "Lot Number."	Located on	Snap Rings	Snap
							box label.	date on the	nber and	Use their work order number and date on the box label.	Use their w	Flare Tubes	Flare
					•		etter "M."	with the I	el, starting	Located on the spool label, starting with the letter "M."	Located on	Copper Tubing	Copper
	22				•		ord "heat."	bove the v	directly a	Located on the box label, directly above the word "heat."	Located on	Brazing Rings	Brazin
							x quantity.	el under bo	ie box lab	Six digit no. located on the box label under box quantity.	Six digit no.	Flare Nuts	Flare
	0766	30140766	J-RING					bers	blity Num	Distinguishing Traceablity Numbers	Distingu		
	A	N/A	501-4-3/16	50						20		r Qty	Order Qty
	No(s)	z	Component(s)	Con		ררכ	devices, LLC	H		392266	39	Order No.	Orde
	Heat Lot/Traceability	Heat Lot/)			1			501-4-3/16-R	501-4	No.	Part No.