								18	6 Meeting			
								q				
				Ciack	163/140		o de la constante de la consta	, or	3 Setup			
	Notes	Inspector			Approved	Time Of Day	Date Part Submitted	nance	1 Maintenance			
		First Part Inspection Record	First Part I				TER P	Down Time Codes	Down	ctions	Special Notes / Instructions	Specia
0												ROUTING:
7												
?												
	3)	211										
		110										
		2										
	3											
									6			2-21-15
cour					0000				,			
Scrap Scrap		Notes		· O	Down Time	Down Time	Cum. Total		Total Pcs.	Prod Hrs.	Emp. Name	Date
	put/8hrs		1 657			Time		Hrs.				
	Thru-		Pre /Hr			Cycle	0	Setup			Mach No	
M.								ability.	uire trace	Do not require traceability.	Caps/Plugs	Caps
		V				• =	Located on the bag followed by "Lot Number."	followed by '	n the bag f	Located or	_	Snap
						e box label.	Use their work order number and date on the box label.	number an	vork order	Use their v	Flare Tubes	Flare
Š						letter "M."	Located on the spool label, starting with the letter "M."	l label, starti	the spoo	Located or	Copper Tubing	Coppe
						word "heat."	Located on the box label, directly above the word "heat."	abel, directly	the box I	Located or	Brazing Rings	Brazir
						ox quantity.	Six digit no. located on the box label under box quantity.	on the box la	). located (	Six digit no	Flare Nuts	Flare
0	20140766	J-RING					ımbers	Distinguishing Traceablity Numbers	uishing Tr	Disting		
	391807	502-6-1/4	5						3		Order Qty	Orde
	No(s)	component(s)	Cor		LLC	devices, LLC	T C		394601	3	Order No.	Ord
Y	Heat Lot/Traceability	apopon+(c)	)				1		502-6-1/4-R	502	Part No.	Par