									6 Meeting	0 1		
										1 13		
	Notes	Inspector	Rev Letter	Mtrl Check	Approved Yes / No	Time Of Day	Date Part Submitted		 Maintenance Tooling 	N. I.		
		First Part Inspection Record	First Part Ir					Codes	Down Time Codes	tions	Special Notes / Instructions	Specia
(ROUTING:
Z	æ											
	1											
	710											
	010											
	S											
									_		(LU)	2-11-15
Scrap		Notes			Down Time Code	Down Time	Cum. Total	Cur	Total Pcs.	Prod Hrs.	Emp. Name	Date
	put/8hrs					Time		Hrs.				
	Thru-		Pcs./Hr			Cycle		Setup			Mach. No.	
								×	Do not require traceability.	Do not requ	Caps/Plugs	Caps
						-	ot Number.	red by "L	Located on the bag followed by "Lot Number."	Located on		Snap
						box label.	date on the	ber and	Use their work order number and date on the box label.	Use their wo	Flare Tubes	Flare
			-			etter "M."	g with the le	el, startin	Located on the spool label, starting with the letter "M."	Located on	Copper Tubing	Coppe
						ord "heat."	above the w	directly	Located on the box label, directly above the word "heat."	Located on	Brazing Rings	Brazir
						x quantity.	oel under bo	e box lak	Six digit no. located on the box label under box quantity.	Six digit no.	Flare Nuts	Flar
27	200100100	E-RING					nbers	blity Nun	Distinguishing Traceablity Numbers	Distingu		
	393833	902-12-1/4	90						1		Order Qty	Ord
	No(s)	component(s)	Con		LLC	devices, LLC	4		394604	39	Order No.	Ord
lity	Heat Lot/Traceability	2000004/21	2						902-12-1/4-K	30Z-T	Part No.	Pai