

1. Overview & specifications

The VentMax Auto-Clean Chimney CH-90 (VentMax, kitchen-chimney) is covered by this service manual for authorised technicians holding the 'kitchen-appliance' skill. It documents diagnosis, fault codes, and board/mechanical-level repair.

Specifications — type: auto-clean wall chimney, suctionM3h: 1200, widthCm: 90, powerW: 180.

Warranty: 60 months. Motor covered 5 years; other parts and labour 12 months.

Reference: <https://support.example-fieldflow.test/ch-90/manual>

VentMax Auto-Clean Chimney CH-90 — Service Manual — page 1

2. Installation & commissioning

Anchor to a load-bearing wall, align the duct with minimal bends, and confirm the auto-clean heater and baffle latch operate.

Record the serial number and commissioning date against the work order. A failed self-test must be cleared before the visit is closed.

3. Fault codes

K1 — Weak suction; motor capacitor degraded. Replace CAP-90. Skill: kitchen-appliance.

K2 — No suction; blower motor seized. Replace MOT-90. Skill: kitchen-appliance.

K5 — Touch panel unresponsive. Replace PCB-90. Skill: kitchen-appliance.

K7 — Auto-clean not heating; coil open. Replace HEAT-90. Skill: kitchen-appliance.

VentMax Auto-Clean Chimney CH-90 — Service Manual — page 3

4. Part replacement — MOT-90 / PCB-90

MOT-90 — Suction blower motor (motor). Isolate mains and follow the safety SOP. Remove the faulty unit, fit MOT-90, and run the self-test. Requires 'kitchen-appliance'. This part is covered under active warranty (free). List price ■2,800.

PCB-90 — Touch + gesture control board (board). Isolate mains and follow the safety SOP. Remove the faulty unit, fit PCB-90, and run the self-test. Requires 'kitchen-appliance'. This part is covered under active warranty (free). List price ■1,200.

5. Part replacement — HEAT-90 / BAFL-90

HEAT-90 — Auto-clean heating coil (heating-element). Isolate mains and follow the safety SOP. Remove the faulty unit, fit HEAT-90, and run the self-test. Requires 'kitchen-appliance'. This part is chargeable (out of warranty scope). List price ■640.

BAFL-90 — Baffle filter set (consumable). Isolate mains and follow the safety SOP. Remove the faulty unit, fit BAFL-90, and run the self-test. Requires 'kitchen-appliance'. This part is chargeable (out of warranty scope). List price ■480.

6. Part replacement — LAMP-90 / CAP-90

LAMP-90 — LED lamp module (consumable). Isolate mains and follow the safety SOP. Remove the faulty unit, fit LAMP-90, and run the self-test. Requires 'kitchen-appliance'. This part is chargeable (out of warranty scope). List price ■220.

CAP-90 — Motor run capacitor (board). Isolate mains and follow the safety SOP. Remove the faulty unit, fit CAP-90, and run the self-test. Requires 'kitchen-appliance'. This part is covered under active warranty (free). List price ■340.

7. Maintenance, safety & warranty

Maintenance: inspect at each visit; clean or replace consumables on the service interval; log any recurring fault code.

Isolate mains before touching the motor run-capacitor.

Warranty annex: under an active warranty, MOT-90, PCB-90, CAP-90 are replaced free with labour. Consumables and cosmetic parts are never covered. If warranty is expired or the fault is outside the original scope, the part is chargeable: a quote is raised and payment is collected before the visit is confirmed.

Policy reference: <https://support.example-fieldflow.test/warranty/v5>

VentMax Auto-Clean Chimney CH-90 — Service Manual — page 7