

Notes:

All vias must be covered with soldermask.

0.1mm drill vias can be plated shut. Any drill that fits in the pad is acceptable. There are 2 plated slots at J1