GILES CHEMICAL CORPORATION							
COMPANY PROCEDURE							
Standard Operating Procedure			Page	:	1 of 1	Revision Date	8/9/2006
Author:	Patrick Owen	Title: (00) Bag Weight Control Chart					

Personnel responsible:

Lead operator, Assistant Operator

Safety:

Steel toed shoes and safety glasses must be worn while in the plant.

Summary:

A control chart can help you to visualize and correct trends in the process. A control chart for Bag Weight Checks is provided to assist in keeping the bagger in calibration.

Procedure:

- 1. If the control chart is full, print a new one from the document system.
- 2. At every bag weight check, record the date, time, initials, and result.
- 3. Graph the result on the graph.
- 4. If the process is out of control (see the rules below), put "Y" or "Yes" under the Recalibrate column and recalibrate the bagger.
- 5. If you recalibrated, check a bag weight again and record the data for that one on the next row.

Out of Control Rules (also shown on the Control Chart)

- 1. If any weight check is out of limits (higher than 50.7 or lower than 49.7), the bag weight is out of control.
- 2. If any 5 checks in a row are above or below the "aim" of 50.2, the bag weight is out of control.
- 3. If any other condition exists that doesn't seem "normal" (for example there is a slow upward or downward trend), assume the bag weight is out of control.

GILES CHEMICAL CORPORATION								
COMPANY PROCEDURE								
Standard	Operating Procedure		Page	:	2 of 1	Revision Date	8/9/2006	
Author:	Patrick Owen	Title: (00) Bag Weight Control Chart						

TRAINING DOCUMENTATION

	EMPLOYEE	TITLE	SIGNATURE	DATE
1				
2				
3				
4				
5				
6				
7				
8				
9				
10				
11				
12				
13				
14				
15				
16				
17				
18				
19				
20				