| * Pownload and Save fite | * New Part File |
|--|--|
| * Open File | * Enable hybrid design |
| * Open sketch | * Save as file with numing convention to the same file |
| * Turn off on grid and snop to grid | A theretifes each shape in same file |
| * Change units to in | * Make the shapes |
| * Turn off /on grid and snop to grid * Change units to in - Tools - Options, parameters - units - length - inch | - Size and locate sketches |
| * Mechanical design - akables - apply designs changes | * Pon't name sketches |
| * Mechanical design - sketches - apply desired changes * Constraint lines - tungent to circles | |
| 1 - Click line and circle | |
| - Pull 11/2 h [1 / 1 / 1 / 1 / 1 / 1 / 1 / 1 / 1 / 1 | |
| right click before placing the aircension | TO 1 |
| 7 Telect langency | Extrude > Pad Extrude Cut > Packet |
| To Irim/Extend the lines and circles | Extrude Cut 7 Pocker |
| - Right click before plucing the dimension - Select Tangency * Trim Extend the lines and circles * Constrain the center cercle | Revolve - Shaft |
| * Exit Sketch * Greate Pad | |
| * Greate Pad | |
| * Edit Pad fouture | |
| * Apply Rec * Rename the Pack * Screenshot for Portfolio | |
| * Rename the Pad | |
| * Screenshot For Portfolio | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |

Date :02/11/20

