
# Lite3DP


Gen 2 dev. kit assembly guide

## REMOVE THE STEPPER MOTOR FROM THE PREASSEMBLY


Manually turn the threaded rod of the motor until it separates downwards




UNSCREW 3 SCREWS (M2 X 8) FROM THE STEPPER MOTOR




### **UNSCREW THE 4 SCREWS IN THE CORNERS OF THE BASE**




### UNSCREW THE FOLLOWING 4 SCREWS




Place the spacer and the motor in the indicated position, under the main board. Screw in the 3 screws, centering them on the gold rings.




### **CONNECT THE STEPPER MOTOR CABLE**




### **CONNECT THE BASE-MAIN BOARD CABLE**



#### REASSEMBLE THE BASE WITH THE 4 CORNER SCREWS



Insert the threaded rod of the stepper motor in the carriage nut and turn it manually until it enters the upper bearing and the support part rests on the main board.



SCREW IN THE 4
SCREWS TO THE
ALUMINUM SPACERS
LOCATED UNDER THE
MAIN BOARD

