

Document No	:	MT-056-SOP-001	STANDARD OPERATING PROCEDURE
Effective Date	:	March 5, 2025	
Revision Status	:		Mechanical Installation on Sparc CNC
Department : Engineering			

1. PURPOSE :

to know how to assemble each hardware part on sparc cnc.

including what types of components are needed.

2. SCOPE :

This document outlines the step-by-step procedure for installing each mechanical sparc cnc part.

3. PROCEDURE DETAILS :

No.	Picture	Detail
1		Install a 6-piece M4 Nut on the bolt side. Kik untuk menerapkan

2		Install M4 bolts on all 4 sides of the base
4		Installing omega clamp with 2 M4 bolts.
5		Installing PG9 at the bottom of the base terminal
		Attach the terminal PCB using M3 bolts on all four sides.

6		Attach the omega clamp with the M4 bolt to the rear side of the basse terminal.
---	---	---