Operating guide

```
Reset uc -- OV
  HOLD UP -- 5 V
  connect USB red led: on, blue led: on
4 Reset uC -- 5 v then o v again. Blue led off
5 folder 8088 test
  file atstamp_memory_programmer.exe
  Enter com port, Enter, press any key to continue
  Press 0: load a program
  Type: "8088slow.dat", Enter
10 press 1: Program memory
11 press 2: verify memory
12 If " OK ", NO Errors:
13 Reset uC -- 5 V
14 HOLD UP -- OV
15 Press Clock reset Push button
16 Program is gonna run
```

Notes:

- * If You use a SUB-USB cable extention, replace it with male female jumpers.
- * Test Your connections with Avometer.
- * if the program runs, hurry up to shoot your video It may not run one more time!!

Required from every team:

Video for a running program, Full schematic, sheet with team number, members names and seat numbers