

Aenderungsbeschreibung/Description of Revision					Kommt vor/Frequency			
war kZ								
Buchst./Rev.Ltr.		Aenderungs-Nr./Revision Notice No.			Bearbeitungsstatus/Lifecycle			
-.5		PR099357			Freigegeben			
Software Reference								
BlueVision New Generation Baseline 100								
Genoline New Generation Baseline 32								
Changes from Var1 Ed 01.09 to Var1 Ed 01.11								
Renaming: WB HighPres Fuel Pump -> AL Wiring PWM_CM1 WB HighPres Fuel Ctrl Valve -> AL Wiring PWM_CM3 WB Raw Water Ctrl Valve -> AL Wiring PWM_CM6 WB Blow Over Ctrl Valve -> AL Wiring PWM_CM7 WB Charge Air Ctrl Valve -> AL Wiring PWM_CM8 WB Flap ETC A -> AL Wiring PWM_CM9 WB Flap ETC B -> AL Wiring PWM_CM10 LO T-RA at PFM Errorcode 1733 AL Wiring PWM_CM4 Errorcode 587 Missing PV's added: 117651, 117661, 117671, 117681, 117611, 117621, 117631, 117641, 117701, 117691 SPN/FMI added: 521965/31 HHI Rel. Humidity SysID corrected from 0010.011300.155.011.2 to 0010.011300.165.001.2 Errorcode 2009/2010 added								
New alarms								
AL MMS Internal Com. Lost HI NOx Wert AL Emission Fault								
Tolerierung/Tolerancing ISO 8015		Masse/Size ISO 14405						
Allgemeintoleranzen/General Tolerances		ISO 2768-mK						
Bauart/Type				Masse/Mass	kg	Format/Size		
BlueVisionNG, GenolineNG		Allgemeine Fertigungsvorschriften nach MMN332 Production Specification per MMN 332		Werkstoff/Material				
Ausf. u.Lieferung Tech. Characteristics				A4				
Oberflaechenschutz Surface Protection								
Oberflaechenschutz Surface Protection		Oberflaechenangaben nach MTN5033 Surface Specification per MTN5033		Halbzeug.Modell Gesenk / Semifinished Product Pattern, Die				
Verwendbar fuer Typ/Applicable to Model R100/R32		Fert.Ber. Man.Adv		Material-Nr./Material No.				
Projekt-/Auftrags-Nr./Project/Order No.		Mont.Ber. Inst.Adv						
Ref.-Nr./ Ref. No. Type1 Var01 ED01_09		Emission ID						
Alle Rechte aus Schutzrechtsanmeldungen vorbehalten. Weitergabe, Vervielfaeltigung oder sonstige Verwertung ohne Zustimmung nicht gestattet. Zuwiderhandlungen verpflichten zum Schadensersatz. All industrial property rights reserved. Disclosure, reproduction or use for any other purpose is prohibited unless our express permission has been given. Any infringement results in liability to pay damages.		WORD		Datum/Date		Name		
		Erstell. Drawn		08.06.2022 10:30:43		schaepers		
		Bearb. Change		29.06.2022 13:49:43		schaepers		
		Norm Std.				ihmor stef		
		Gepr. Checked				ihmor stef		
				Benennung/ Title			TB / Table	
				DOKUMENTATION				
				BVNG/GLNG Alarmbeschreibung				
				DOCUMENTATION				
				BVNG/GLNG Alarm description				
		Zeichnungs-Nr./Drawing No.			ZNG00046770			
					Blatt/ Sheet			

Aenderungsbeschreibung/Description of Revision war kZ		Kommt vor/Frequency	
Buchst./Rev.Ltr. -.5	Aenderungs-Nr./Revision Notice No. PR099357	Bearbeitungsstatus/Lifecycle Freigegeben	
SD P-Gas Inlet before Filter SD P-Gas Inlet after Filter SD P-Gas GRU Block-Bleed SD P-Gas GRU Outlet SD T-Gas GRU Outlet SD P-Control Air GRU IP-Conv SD P-Control Air GRU Inlet LOLO P-Gas GRU Inlet HIHI P-Gas GRU Inlet LO P-Gas Rail HI P-Gas Rail HIHI P-Fuel Return Path HIHI P-Coolant AL NH3 SCR Outlet SlipMon AL RA Post Cooling Aborted HI EGAT HotShutdown Count AL Security Mode PCV Open 1 AL Security Mode PCV Open 2 HI MMS Main Power LO MMS Main Power HI MMS Emerg Power LO MMS Emerg Power AL EGAT IMO3 Mode Fail AL EGAT Safety Function Fail AL Priming Pump Overcurrent AL Com To SB Gateway Lost AL Emission SPU Check Fail AL Com To FMCS J1939 Lost AL Com To FMCS CANopen Lost			
	Zeichnungs-Nr./Drawing No.	ZNG00046770	Blatt/ Sheet 2 von/of 185
	Material-Nr./Material No.	XZ00E52000043	
Alle Rechte aus Schutzrechtsanmeldungen vorbehalten. Weitergabe, Vervielfältigung oder sonstige Verwertung ohne Zustimmung nicht gestattet. Zuwiderhandlungen verpflichten zum Schadensersatz. All industrial property rights reserved. Disclosure, reproduction or use for any other purpose is prohibited unless our express permission has been given. Any infringement results in liability to pay damages.			

Aenderungsbeschreibung/Description of Revision war kZ		Kommt vor/Frequency
Buchst./Rev.Ltr. -5	Aenderungs-Nr./Revision Notice No. PR099357	Bearbeitungsstatus/Lifecycle Freigegeben

Alarm Description

Product	SysID	Alarm Name	Alarm Description
BVNG/GLNG	0011.025101.215.001.2	SD P-Lube Oil SaSy	The safety system sensor signal for lube oil pressure is outside the defined sensor signal range. The safety system lube oil pressure information is not available anymore for indication or monitoring. The safety functions related to this signal are not available anymore.
BVNG/GLNG	0011.015201.215.001.2	SD T-Coolant SaSy	The safety system sensor signal for coolant temperature is outside the defined sensor signal range. The safety system coolant temperature information is not available anymore for indication or monitoring. The safety functions related to this signal are not available anymore.
BVNG/GLNG	0010.006201.215.011.2	SD T-Exhaust A1	The sensor signal for the single exhaust temperature of the specified cylinder is outside the defined sensor signal range. This measuring point is not available anymore for indication or monitoring. Configured safety functions related to this signal are not available anymore.
BVNG/GLNG	0010.006201.215.021.2	SD T-Exhaust A2	The sensor signal for the single exhaust temperature of the specified cylinder is outside the defined sensor signal range. This measuring point is not available anymore for indication or monitoring. Configured safety functions related to this signal are not available anymore.
BVNG/GLNG	0010.006201.215.031.2	SD T-Exhaust A3	The sensor signal for the single exhaust temperature of the specified cylinder is outside the defined sensor signal range. This measuring point is not available anymore for indication or monitoring. Configured safety functions related to this signal are not available anymore.
BVNG/GLNG	0010.006201.215.041.2	SD T-Exhaust A4	The sensor signal for the single exhaust temperature of the specified cylinder is outside the defined sensor signal range. This measuring point is not available anymore for indication or monitoring. Configured safety functions related to this signal are not available anymore.
BVNG/GLNG	0010.006201.215.051.2	SD T-Exhaust A5	The sensor signal for the single exhaust temperature of the specified cylinder is outside the defined sensor signal range. This measuring point is not available anymore for indication or monitoring. Configured safety functions related to this signal are not available anymore.
BVNG/GLNG	0010.006201.215.061.2	SD T-Exhaust A6	The sensor signal for the single exhaust temperature of the specified cylinder is outside the defined sensor signal range. This measuring point is not available anymore for indication or monitoring. Configured safety functions related to this signal are not available anymore.
BVNG/GLNG	0010.006201.215.071.2	SD T-Exhaust A7	The sensor signal for the single exhaust temperature of the specified cylinder is outside the defined sensor signal range. This measuring point is not available anymore for indication or monitoring. Configured safety functions related to this signal are not available anymore.
BVNG/GLNG	0010.006201.215.081.2	SD T-Exhaust A8	The sensor signal for the single exhaust temperature of the specified cylinder is outside the defined sensor signal range. This measuring point is not available anymore for indication or monitoring. Configured safety functions related to this signal are not available anymore.
BVNG/GLNG	0010.006201.215.091.2	SD T-Exhaust A9	The sensor signal for the single exhaust temperature of the specified cylinder is outside the defined sensor signal range. This measuring point is not available anymore for indication or monitoring. Configured safety functions related to this signal are not available anymore.
BVNG/GLNG	0010.006201.215.101.2	SD T-Exhaust A10	The sensor signal for the single exhaust temperature of the specified cylinder is outside the defined sensor signal range. This measuring point is not available anymore for indication or monitoring. Configured safety functions related to this signal are not available anymore.
BVNG/GLNG	0010.006202.215.011.2	SD T-Exhaust B1	The sensor signal for the single exhaust temperature of the specified cylinder is outside the defined sensor signal range. This measuring point is not available anymore for indication or monitoring. Configured safety functions related to this signal are not available anymore.
BVNG/GLNG	0010.006202.215.021.2	SD T-Exhaust B2	The sensor signal for the single exhaust temperature of the specified cylinder is outside the defined sensor signal range. This measuring point is not available anymore for indication or monitoring. Configured safety functions related to this signal are not available anymore.
BVNG/GLNG	0010.006202.215.031.2	SD T-Exhaust B3	The sensor signal for the single exhaust temperature of the specified cylinder is outside the defined sensor signal range. This measuring point is not available anymore for indication or monitoring. Configured safety functions related to this signal are not available anymore.
BVNG/GLNG	0010.006202.215.041.2	SD T-Exhaust B4	The sensor signal for the single exhaust temperature of the specified cylinder is outside the defined sensor signal range. This measuring point is not available anymore for indication or monitoring. Configured safety functions related to this signal are not available anymore.
BVNG/GLNG	0010.006202.215.051.2	SD T-Exhaust B5	The sensor signal for the single exhaust temperature of the specified cylinder is outside the defined sensor signal range. This measuring point is not available anymore for indication or monitoring. Configured safety functions related to this signal are not available anymore.
BVNG/GLNG	0010.006202.215.061.2	SD T-Exhaust B6	The sensor signal for the single exhaust temperature of the specified cylinder is outside the defined sensor signal range. This measuring point is not available anymore for indication or monitoring. Configured safety functions related to this signal are not available anymore.
BVNG/GLNG	0010.006202.215.071.2	SD T-Exhaust B7	The sensor signal for the single exhaust temperature of the specified cylinder is outside the defined sensor signal range. This measuring point is not available anymore for indication or monitoring. Configured safety functions related to this signal are not available anymore.
BVNG/GLNG	0010.006202.215.081.2	SD T-Exhaust B8	The sensor signal for the single exhaust temperature of the specified cylinder is outside the defined sensor signal range. This measuring point is not available anymore for indication or monitoring. Configured safety functions related to this signal are not available anymore.
BVNG/GLNG	0010.006202.215.091.2	SD T-Exhaust B9	The sensor signal for the single exhaust temperature of the specified cylinder is outside the defined sensor signal range. This measuring point is not available anymore for indication or monitoring. Configured safety functions related to this signal are not available anymore.
BVNG/GLNG	0010.006202.215.101.2	SD T-Exhaust B10	The sensor signal for the single exhaust temperature of the specified cylinder is outside the defined sensor signal range. This measuring point is not available anymore for indication or monitoring. Configured safety functions related to this signal are not available anymore.
BVNG	0010.040704.205.001.2	AL Startpilot Fail	The connector to the start pilot have a wire break or short circuit.

	Zeichnungs-Nr./Drawing No.	ZNG00046770	Blatt/ Sheet 3 von/of 185
	Material-Nr./Material No.	XZ00E52000043	

Alle Rechte aus Schutzrechtsanmeldungen vorbehalten. Weitergabe, Vervielfältigung oder sonstige Verwertung ohne Zustimmung nicht gestattet. Zuwiderhandlungen verpflichten zum Schadensersatz.
All industrial property rights reserved. Disclosure, reproduction or use for any other purpose is prohibited unless our express permission has been given. Any infringement results in liability to pay damages.

Aenderungsbeschreibung/Description of Revision war kZ		Kommt vor/Frequency
Buchst./Rev.Ltr. -5	Aenderungs-Nr./Revision Notice No. PR099357	Bearbeitungsstatus/Lifecycle Freigegeben

Product	SysID	Alarm Name	Alarm Description
BVNG	0011.020101.105.011.2	LO P-Fuel Common Rail A SaSy	Low Limit of fuel pressure in rail A (safety system)
BVNG	0011.020101.105.021.2	LO P-Fuel Common Rail B SaSy	Low Limit of fuel pressure in rail B (safety system)
BVNG	0010.025106.105.001.2	LO P-Lube Oil Last Bearing	Low Limit of lube oil pressure last bearing
BVNG	0010.025108.105.001.2	LO P-Piston Cooling Oil	Low Limit of lube oil pressure piston cool
BVNG	0010.016102.105.001.2	LO P-Raw Water before Pump	Low Limit of raw water pressure before pump reached
BVNG	0010.010101.105.001.2	LO P-Control Air	Low Limit of control air pressure reached
BVNG	0010.025106.115.001.2	LOLO P-Lube Oil Last Bearing	Lowest Limit of lube oil pressure last bearing reached
BVNG	0010.025108.115.001.2	LOLO P-Piston Cooling Oil	Lowest Limit of lube oil pressure piston cool
BVNG	0010.025109.155.001.2	HI P-Piston Cool.Oil Filt.Diff	High Limit of fuel pressure in return path
BVNG	0010.006101.155.001.2	HI P-Exhaust back	High Limit of exhaust pressure back (turbocharger)
BVNG	0010.056001.155.051.2	HI ETC 5 Speed	Speed of engine turbo charger 5 too high (limit 1).
BVNG	0010.006101.165.001.2	HIHI P-Exhaust back	Highest Limit of exhaust pressure back (turbocharger)
BVNG	0010.056001.165.051.2	HIHI ETC 5 Overspeed	Speed of engine turbo charger 5 too high (limit 2).
BVNG	1.0021.075001.205.001.2	AL Gear SaSy Comb Alarm Red	The gearbox safty system have a common red alarm. Check for the single alarm on LOP
BVNG	1.0021.075003.205.001.2	AL Gear SaSy Comb Alarm Yellow	The gearbox safty system have a common yellow alarm. Check for the single alarm on LOP
BVNG	0010.020101.225.011.2	TD P-Fuel Common Rail A	The fuel pressure difference between the redundant common rail pressure sensors is too high on engine Bank A.
BVNG	0010.020101.225.021.2	TD P-Fuel Common Rail B	The fuel pressure difference between the redundant common rail pressure sensors is too high on engine Bank B
BVNG	1.0021.043002.205.001.2	AL Gear SaSy Shutdown Expected	A limit violation was detected by the gearbox safty system and alarmed (pre warning, yellow alarm). A worsening situation will cause an automatic security shutdown.
BVNG	1.0080.059005.205.001.2	AL Clutch interlock RCS	The clutch interlock input is active, gearbox will stay in neutral.
BVNG	1.0021.043102.205.001.2	AL Security Shutdown Gear SaSy	An security shutdown was initiated. The security shutdown was initiated by an engine- or gear safety function. This alarm is attended by a second alarm indicating which problem caused the shutdown. Most security shutdowns might be overridable by the operator on his own risk. Several shutdowns are triggered within the ECU engine monitoring system. The safety system is also able to trigger a security shutdown. Gearbox safety shutdowns are triggered by the monitoring- and safety system of the SPU.
BVNG	0070.075804.245.001.2	SE Sysbus Duplicate Node	There are two or more systembus devices (SPU and SCUs) with the same systembus node address, which is not allowed. The Communication between componetes (LOP, displays, control lever, not MTU devices) may be distrubed. == > Check the the hex rotary encoder switches of each SPU and SCU.
BVNG	0010.006402.165.011.2	HIHI T-Exhaust after LP ETC	Highest Limit of exhaust temperature (turbocharger)
BVNG	0070.075232.205.011.2	AL MCS Dim PAN Lost CS1	The communication to Dim PAN on first (#1) control stand is interrupted. Dimming from the PAN won't have a effect.
BVNG	0070.075232.205.021.2	AL MCS Dim PAN Lost CS2	The communication to Dim PAN on second (#2) control stand is interrupted. Dimming from the PAN won't have a effect.

	Zeichnungs-Nr./Drawing No.	ZNG00046770	Blatt/ Sheet 4 von/of 185
	Material-Nr./Material No.	XZ00E52000043	

Alle Rechte aus Schutzrechtsanmeldungen vorbehalten. Weitergabe, Vervielfältigung oder sonstige Verwertung ohne Zustimmung nicht gestattet. Zuwiderhandlungen verpflichten zum Schadensersatz.
All industrial property rights reserved. Disclosure, reproduction or use for any other purpose is prohibited unless our express permission has been given. Any infringement results in liability to pay damages.

Aenderungsbeschreibung/Description of Revision war kZ		Kommt vor/Frequency
Buchst./Rev.Ltr. -.5	Aenderungs-Nr./Revision Notice No. PR099357	Bearbeitungsstatus/Lifecycle Freigegeben

Product	SysID	Alarm Name	Alarm Description
BVNG	0070.075232.205.031.2	AL MCS Dim PAN Lost CS3	The communication to Dim PAN on third (#3) control stand is interrupted. Dimming from the PAN won't have a effect.
BVNG	0070.075232.205.041.2	AL MCS Dim PAN Lost CS4	The communication to Dim PAN on fourth (#4) control stand is interrupted. Dimming from the PAN won't have a effect.
BVNG	0070.075232.205.051.2	AL MCS Dim PAN Lost CS5	The communication to Dim PAN on fifth (#5) control stand is interrupted. Dimming from the PAN won't have a effect.
BVNG	0070.075232.205.061.2	AL MCS Dim PAN Lost CS6	The communication to Dim PAN on sixth (#6) control stand is interrupted. Dimming from the PAN won't have a effect.
BVNG/GLNG	0010.057303.205.001.2	AL ECU Defect	Fatal internal ECU failure. ECU has to be replaced
BVNG/GLNG	0011.000501.165.001.2	HHI Engine Overspeed SaSy	An engine overspeed was detected by the safety system. This alarm will normally cause an automatic emergency stop.
BVNG/GLNG	0011.025101.105.001.2	LO P-Lube Oil SaSy	A low engine lube oil pressure was detected by the safety system. A worsening situation could trigger a safety reaction.
BVNG/GLNG	0011.025101.115.001.2	LOLO P-Lube Oil SaSy	A very low engine lube oil pressure was detected by the safety system. This alarm will normally cause an automatic security shutdown. The safety reaction is alarmed with an separate alarm.
BVNG/GLNG	0011.015201.155.001.2	HI T-Coolant SaSy	A high engine coolant temperature was detected by the safety system. A worsening situation could trigger a safety reaction.
BVNG/GLNG	0011.015201.165.001.2	HHI T-Coolant SaSy	A very high engine coolant temperature was detected by the safety system. This alarm will normally cause an automatic safety function. The safety reaction is alarmed with an separate alarm.
BVNG/GLNG	0011.043301.255.001.2	WB SaSy Emergency Stop Output	The safety system detected an open loop of it's emergency stop output. An automatic emergency stop function is not available anymore.
BVNG/GLNG	0011.043302.265.001.2	SC SaSy Emergency Stop Output	The safety system detected a short circuit of it's emergency stop output. An automatic emergency stop function is not available anymore.
BVNG/GLNG	0010.055202.155.001.2	HI T-Bearing Mean	The average bearing temperature is too high.
BVNG/GLNG	0010.006201.155.011.2	HI T-Exhaust A1	The temperature of cylinder A1 compared to the average exhaust temperature is too high.
BVNG/GLNG	0010.006201.155.021.2	HI T-Exhaust A2	The temperature of cylinder A2 compared to the average exhaust temperature is too high.
BVNG/GLNG	0010.006201.155.031.2	HI T-Exhaust A3	The temperature of cylinder A3 compared to the average exhaust temperature is too high.
BVNG/GLNG	0010.006201.155.041.2	HI T-Exhaust A4	The temperature of cylinder A4 compared to the average exhaust temperature is too high.
BVNG/GLNG	0010.006201.155.051.2	HI T-Exhaust A5	The temperature of cylinder A5 compared to the average exhaust temperature is too high.
BVNG/GLNG	0010.006201.155.061.2	HI T-Exhaust A6	The temperature of cylinder A6 compared to the average exhaust temperature is too high.
BVNG/GLNG	0010.006201.155.071.2	HI T-Exhaust A7	The temperature of cylinder A7 compared to the average exhaust temperature is too high.
BVNG/GLNG	0010.006201.155.081.2	HI T-Exhaust A8	The temperature of cylinder A8 compared to the average exhaust temperature is too high.
BVNG/GLNG	0010.006201.155.091.2	HI T-Exhaust A9	The temperature of cylinder A9 compared to the average exhaust temperature is too high.
BVNG/GLNG	0010.006201.155.101.2	HI T-Exhaust A10	The temperature of cylinder A10 compared to the average exhaust temperature is too high.
BVNG/GLNG	0010.006202.155.011.2	HI T-Exhaust B1	The temperature of cylinder B1 compared to the average exhaust temperature is too high.

	Zeichnungs-Nr./Drawing No.	ZNG00046770	Blatt/ Sheet 5 von/of 185
	Material-Nr./Material No.	XZ00E52000043	
Alle Rechte aus Schutzrechtsanmeldungen vorbehalten. Weitergabe, Vervielfältigung oder sonstige Verwertung ohne Zustimmung nicht gestattet. Zuwiderhandlungen verpflichten zum Schadensersatz. All industrial property rights reserved. Disclosure, reproduction or use for any other purpose is prohibited unless our express permission has been given. Any infringement results in liability to pay damages.			

Aenderungsbeschreibung/Description of Revision war kZ		Kommt vor/Frequency
Buchst./Rev.Ltr. -5	Aenderungs-Nr./Revision Notice No. PR099357	Bearbeitungsstatus/Lifecycle Freigegeben

Product	SysID	Alarm Name	Alarm Description
BVNG/GLNG	0010.006202.155.021.2	HI T-Exhaust B2	The temperature of cylinder B2 compared to the average exhaust temperature is too high.
BVNG/GLNG	0010.006202.155.031.2	HI T-Exhaust B3	The temperature of cylinder B3 compared to the average exhaust temperature is too high.
BVNG/GLNG	0010.006202.155.041.2	HI T-Exhaust B4	The temperature of cylinder B4 compared to the average exhaust temperature is too high.
BVNG/GLNG	0010.006202.155.051.2	HI T-Exhaust B5	The temperature of cylinder B5 compared to the average exhaust temperature is too high.
BVNG/GLNG	0010.006202.155.061.2	HI T-Exhaust B6	The temperature of cylinder B6 compared to the average exhaust temperature is too high.
BVNG/GLNG	0010.006202.155.071.2	HI T-Exhaust B7	The temperature of cylinder B7 compared to the average exhaust temperature is too high.
BVNG/GLNG	0010.006202.155.081.2	HI T-Exhaust B8	The temperature of cylinder B8 compared to the average exhaust temperature is too high.
BVNG/GLNG	0010.006202.155.091.2	HI T-Exhaust B9	The temperature of cylinder B9 compared to the average exhaust temperature is too high.
BVNG/GLNG	0010.006202.155.101.2	HI T-Exhaust B10	The temperature of cylinder B10 compared to the average exhaust temperature is too high.
BVNG/GLNG	0010.055201.155.011.2	HI T-Bearing 1	The temperature of bearing 1 is too high
BVNG/GLNG	0010.055201.155.021.2	HI T-Bearing 2	The temperature of bearing 2 is too high
BVNG/GLNG	0010.055201.155.031.2	HI T-Bearing 3	The temperature of bearing 3 is too high
BVNG/GLNG	0010.055201.155.041.2	HI T-Bearing 4	The temperature of bearing 4 is too high
BVNG/GLNG	0010.055201.155.051.2	HI T-Bearing 5	The temperature of bearing 5 is too high
BVNG/GLNG	0010.055201.155.061.2	HI T-Bearing 6	The temperature of bearing 6 is too high
BVNG/GLNG	0010.055201.155.071.2	HI T-Bearing 7	The temperature of bearing 7 is too high
BVNG/GLNG	0010.055201.155.081.2	HI T-Bearing 8	The temperature of bearing 8 is too high
BVNG/GLNG	0010.055201.155.091.2	HI T-Bearing 9	The temperature of bearing 9 is too high
BVNG/GLNG	0010.055201.155.101.2	HI T-Bearing 10	The temperature of bearing 10 is too high
BVNG/GLNG	0010.055201.155.111.2	HI T-Bearing 11	The temperature of bearing 11 is too high
BVNG/GLNG	0010.055201.165.011.2	HIHI T-Bearing 1	The temperature of bearing 1 is very high. This alarm might cause an automatic safety function. The safety reaction would be alarmed with a separate alarm.
BVNG/GLNG	0010.055201.165.021.2	HIHI T-Bearing 2	The temperature of bearing 2 is very high. This alarm might cause an automatic safety function. The safety reaction would be alarmed with a separate alarm.
BVNG/GLNG	0010.055201.165.031.2	HIHI T-Bearing 3	The temperature of bearing 3 is very high. This alarm might cause an automatic safety function. The safety reaction would be alarmed with a separate alarm.
BVNG/GLNG	0010.055201.165.041.2	HIHI T-Bearing 4	The temperature of bearing 4 is very high. This alarm might cause an automatic safety function. The safety reaction would be alarmed with a separate alarm.

	Zeichnungs-Nr./Drawing No.	ZNG00046770	Blatt/ Sheet 6 von/of 185
	Material-Nr./Material No.	XZ00E52000043	

Alle Rechte aus Schutzrechtsanmeldungen vorbehalten. Weitergabe, Vervielfältigung oder sonstige Verwertung ohne Zustimmung nicht gestattet. Zuwiderhandlungen verpflichten zum Schadensersatz.
All industrial property rights reserved. Disclosure, reproduction or use for any other purpose is prohibited unless our express permission has been given. Any infringement results in liability to pay damages.

Aenderungsbeschreibung/Description of Revision war kZ		Kommt vor/Frequency
Buchst./Rev.Ltr. -5	Aenderungs-Nr./Revision Notice No. PR099357	Bearbeitungsstatus/Lifecycle Freigegeben

Product	SysID	Alarm Name	Alarm Description
BVNG/GLNG	0010.055201.165.051.2	HIHI T-Bearing 5	The temperature of bearing 5 is very high. This alarm might cause an automatic safety function. The safety reaction would be alarmed with a separate alarm.
BVNG/GLNG	0010.055201.165.061.2	HIHI T-Bearing 6	The temperature of bearing 6 is very high. This alarm might cause an automatic safety function. The safety reaction would be alarmed with a separate alarm.
BVNG/GLNG	0010.055201.165.071.2	HIHI T-Bearing 7	The temperature of bearing 7 is very high. This alarm might cause an automatic safety function. The safety reaction would be alarmed with a separate alarm.
BVNG/GLNG	0010.055201.165.081.2	HIHI T-Bearing 8	The temperature of bearing 8 is very high. This alarm might cause an automatic safety function. The safety reaction would be alarmed with a separate alarm.
BVNG/GLNG	0010.055201.165.091.2	HIHI T-Bearing 9	The temperature of bearing 9 is very high. This alarm might cause an automatic safety function. The safety reaction would be alarmed with a separate alarm.
BVNG/GLNG	0010.055201.165.101.2	HIHI T-Bearing 10	The temperature of bearing 10 is very high. This alarm might cause an automatic safety function. The safety reaction would be alarmed with a separate alarm.
BVNG/GLNG	0010.055201.165.111.2	HIHI T-Bearing 11	The temperature of bearing 11 is very high. This alarm might cause an automatic safety function. The safety reaction would be alarmed with a separate alarm.
BVNG/GLNG	0010.006201.105.011.2	LO T-Exhaust A1	The temperature of cylinder A1 compared to the average exhaust temperature is too low.
BVNG/GLNG	0010.006201.105.021.2	LO T-Exhaust A2	The temperature of cylinder A2 compared to the average exhaust temperature is too low.
BVNG/GLNG	0010.006201.105.031.2	LO T-Exhaust A3	The temperature of cylinder A3 compared to the average exhaust temperature is too low.
BVNG/GLNG	0010.006201.105.041.2	LO T-Exhaust A4	The temperature of cylinder A4 compared to the average exhaust temperature is too low.
BVNG/GLNG	0010.006201.105.051.2	LO T-Exhaust A5	The temperature of cylinder A5 compared to the average exhaust temperature is too low.
BVNG/GLNG	0010.006201.105.061.2	LO T-Exhaust A6	The temperature of cylinder A6 compared to the average exhaust temperature is too low.
BVNG/GLNG	0010.006201.105.071.2	LO T-Exhaust A7	The temperature of cylinder A7 compared to the average exhaust temperature is too low.
BVNG/GLNG	0010.006201.105.081.2	LO T-Exhaust A8	The temperature of cylinder A8 compared to the average exhaust temperature is too low.
BVNG/GLNG	0010.006201.105.091.2	LO T-Exhaust A9	The temperature of cylinder A9 compared to the average exhaust temperature is too low.
BVNG/GLNG	0010.006201.105.101.2	LO T-Exhaust A10	The temperature of cylinder A10 compared to the average exhaust temperature is too low.
BVNG/GLNG	0010.006202.105.011.2	LO T-Exhaust B1	The temperature of cylinder B1 compared to the average exhaust temperature is too low.
BVNG/GLNG	0010.006202.105.021.2	LO T-Exhaust B2	The temperature of cylinder B2 compared to the average exhaust temperature is too low.
BVNG/GLNG	0010.006202.105.031.2	LO T-Exhaust B3	The temperature of cylinder B3 compared to the average exhaust temperature is too low.
BVNG/GLNG	0010.006202.105.041.2	LO T-Exhaust B4	The temperature of cylinder B4 compared to the average exhaust temperature is too low.
BVNG/GLNG	0010.006202.105.051.2	LO T-Exhaust B5	The temperature of cylinder B5 compared to the average exhaust temperature is too low.
BVNG/GLNG	0010.006202.105.061.2	LO T-Exhaust B6	The temperature of cylinder B6 compared to the average exhaust temperature is too low.
BVNG/GLNG	0010.006202.105.071.2	LO T-Exhaust B7	The temperature of cylinder B7 compared to the average exhaust temperature is too low.

	Zeichnungs-Nr./Drawing No.	ZNG00046770	Blatt/ Sheet 7 von/of 185
	Material-Nr./Material No.	XZ00E52000043	
Alle Rechte aus Schutzrechtsanmeldungen vorbehalten. Weitergabe, Vervielfältigung oder sonstige Verwertung ohne Zustimmung nicht gestattet. Zuwiderhandlungen verpflichten zum Schadensersatz. All industrial property rights reserved. Disclosure, reproduction or use for any other purpose is prohibited unless our express permission has been given. Any infringement results in liability to pay damages.			

Aenderungsbeschreibung/Description of Revision war KZ		Kommt vor/Frequency
Buchst./Rev.Ltr. -.5	Aenderungs-Nr./Revision Notice No. PR099357	Bearbeitungsstatus/Lifecycle Freigegeben

Product	SysID	Alarm Name	Alarm Description
BVNG/GLNG	0010.006202.105.081.2	LO T-Exhaust B8	The temperature of cylinder B8 compared to the average exhaust temperature is too low.
BVNG/GLNG	0010.006202.105.091.2	LO T-Exhaust B9	The temperature of cylinder B9 compared to the average exhaust temperature is too low.
BVNG/GLNG	0010.006202.105.101.2	LO T-Exhaust B10	The temperature of cylinder B10 compared to the average exhaust temperature is too low.
BVNG/GLNG	0010.016101.105.001.2	LO P-Raw Water	The raw water pressure after the pump is too low (limit 1)
BVNG/GLNG	0010.006207.205.001.2	AL Exhaust Monitoring Fail	The exhaust monitoring failed due to missing cylinder cut-out status. Can be caused by a communication loss between the ECU and the monitoring device.
BVNG/GLNG	0011.043501.205.001.2	AL Security Channel def. SaSy	A sensor of the safety system was detected "Sensor Defect". The respective safety function is not available anymore.
BVNG/GLNG	0011.015201.225.001.2	TD T-Coolant	The temperature difference between the redundant coolant temperature sensors is too high.
BVNG/GLNG	0011.025101.225.001.2	TD P-Lube Oil	The pressure difference between the redundant lube oil pressure sensors is too high.
BVNG/GLNG	0010.006206.205.001.2	AL T-Exhaust L2 above/below	One of the single exhaust temperatures is well above or below the average exhaust temperature. This might trigger a safety function. The safety reaction would be alarmed with an separate alarm.
BVNG/GLNG	0010.025601.155.011.2	HI T-Splash Oil B1	The temperature of the conrod bearing splash oil measured at position 1 at the B-side of the crank case is too high
BVNG/GLNG	0010.025601.155.021.2	HI T-Splash Oil B2	The temperature of the conrod bearing splash oil measured at position 2 at the B-side of the crank case is too high
BVNG/GLNG	0010.025601.155.031.2	HI T-Splash Oil B3	The temperature of the conrod bearing splash oil measured at position 3 at the B-side of the crank case is too high
BVNG/GLNG	0010.025601.155.041.2	HI T-Splash Oil B4	The temperature of the conrod bearing splash oil measured at position 4 at the B-side of the crank case is too high
BVNG/GLNG	0010.025601.155.051.2	HI T-Splash Oil B5	The temperature of the conrod bearing splash oil measured at position 5 at the B-side of the crank case is too high
BVNG/GLNG	0010.025601.155.061.2	HI T-Splash Oil B6	The temperature of the conrod bearing splash oil measured at position 6 at the B-side of the crank case is too high
BVNG/GLNG	0010.025601.155.071.2	HI T-Splash Oil B7	The temperature of the conrod bearing splash oil measured at position 7 at the B-side of the crank case is too high
BVNG/GLNG	0010.025601.155.081.2	HI T-Splash Oil B8	The temperature of the conrod bearing splash oil measured at position 8 at the B-side of the crank case is too high
BVNG/GLNG	0010.025601.155.091.2	HI T-Splash Oil B9	The temperature of the conrod bearing splash oil measured at position 9 at the B-side of the crank case is too high
BVNG/GLNG	0010.025601.155.101.2	HI T-Splash Oil B10	The temperature of the conrod bearing splash oil measured at position 10 at the B-side of the crank case is too high
BVNG/GLNG	0010.025601.165.011.2	HIHI T-Splash Oil B1	The temperature of the conrod bearing splash oil measured at position 1 at the B-side of the crank case is very high
BVNG/GLNG	0010.025601.165.021.2	HIHI T-Splash Oil B2	The temperature of the conrod bearing splash oil measured at position 2 at the B-side of the crank case is very high
BVNG/GLNG	0010.025601.165.031.2	HIHI T-Splash Oil B3	The temperature of the conrod bearing splash oil measured at position 3 at the B-side of the crank case is very high
BVNG/GLNG	0010.025601.165.041.2	HIHI T-Splash Oil B4	The temperature of the conrod bearing splash oil measured at position 4 at the B-side of the crank case is very high
BVNG/GLNG	0010.025601.165.051.2	HIHI T-Splash Oil B5	The temperature of the conrod bearing splash oil measured at position 5 at the B-side of the crank case is very high

	Zeichnungs-Nr./Drawing No.	ZNG00046770	Blatt/ Sheet 8 von/of 185
	Material-Nr./Material No.	XZ00E52000043	
Alle Rechte aus Schutzrechtsanmeldungen vorbehalten. Weitergabe, Vervielfältigung oder sonstige Verwertung ohne Zustimmung nicht gestattet. Zuwiderhandlungen verpflichten zum Schadensersatz. All industrial property rights reserved. Disclosure, reproduction or use for any other purpose is prohibited unless our express permission has been given. Any infringement results in liability to pay damages.			

Aenderungsbeschreibung/Description of Revision war KZ		Kommt vor/Frequency
Buchst./Rev.Ltr. -5	Aenderungs-Nr./Revision Notice No. PR099357	Bearbeitungsstatus/Lifecycle Freigegeben

Product	SysID	Alarm Name	Alarm Description
BVNG/GLNG	0010.025601.165.061.2	HIHI T-Splash Oil B6	The temperature of the conrod bearing splash oil measured at position 6 at the B-side of the crank case is very high
BVNG/GLNG	0010.025601.165.071.2	HIHI T-Splash Oil B7	The temperature of the conrod bearing splash oil measured at position 7 at the B-side of the crank case is very high
BVNG/GLNG	0010.025601.165.081.2	HIHI T-Splash Oil B8	The temperature of the conrod bearing splash oil measured at position 8 at the B-side of the crank case is very high
BVNG/GLNG	0010.025601.165.091.2	HIHI T-Splash Oil B9	The temperature of the conrod bearing splash oil measured at position 9 at the B-side of the crank case is very high
BVNG/GLNG	0010.025601.165.101.2	HIHI T-Splash Oil B10	The temperature of the conrod bearing splash oil measured at position 10 at the B-side of the crank case is very high
BVNG/GLNG	0010.025604.205.011.2	AL Splash Oil Cal not Poss	The internal splash oil temperature calibration process was not successful.
BVNG/GLNG	0010.055201.215.011.2	SD T-Bearing 1	The temperature sensor signal for the specified bearing is outside the defined sensor signal range. This measuring point is not available anymore for indication or monitoring. Configured safety functions related to this signal are not available anymore.
BVNG/GLNG	0010.055201.215.021.2	SD T-Bearing 2	The temperature sensor signal for the specified bearing is outside the defined sensor signal range. This measuring point is not available anymore for indication or monitoring. Configured safety functions related to this signal are not available anymore.
BVNG/GLNG	0010.055201.215.031.2	SD T-Bearing 3	The temperature sensor signal for the specified bearing is outside the defined sensor signal range. This measuring point is not available anymore for indication or monitoring. Configured safety functions related to this signal are not available anymore.
BVNG/GLNG	0010.055201.215.041.2	SD T-Bearing 4	The temperature sensor signal for the specified bearing is outside the defined sensor signal range. This measuring point is not available anymore for indication or monitoring. Configured safety functions related to this signal are not available anymore.
BVNG/GLNG	0010.055201.215.051.2	SD T-Bearing 5	The temperature sensor signal for the specified bearing is outside the defined sensor signal range. This measuring point is not available anymore for indication or monitoring. Configured safety functions related to this signal are not available anymore.
BVNG/GLNG	0010.055201.215.061.2	SD T-Bearing 6	The temperature sensor signal for the specified bearing is outside the defined sensor signal range. This measuring point is not available anymore for indication or monitoring. Configured safety functions related to this signal are not available anymore.
BVNG/GLNG	0010.055201.215.071.2	SD T-Bearing 7	The temperature sensor signal for the specified bearing is outside the defined sensor signal range. This measuring point is not available anymore for indication or monitoring. Configured safety functions related to this signal are not available anymore.
BVNG/GLNG	0010.055201.215.081.2	SD T-Bearing 8	The temperature sensor signal for the specified bearing is outside the defined sensor signal range. This measuring point is not available anymore for indication or monitoring. Configured safety functions related to this signal are not available anymore.
BVNG/GLNG	0010.055201.215.091.2	SD T-Bearing 9	The temperature sensor signal for the specified bearing is outside the defined sensor signal range. This measuring point is not available anymore for indication or monitoring. Configured safety functions related to this signal are not available anymore.
BVNG/GLNG	0010.055201.215.101.2	SD T-Bearing 10	The temperature sensor signal for the specified bearing is outside the defined sensor signal range. This measuring point is not available anymore for indication or monitoring. Configured safety functions related to this signal are not available anymore.
BVNG/GLNG	0010.055201.215.111.2	SD T-Bearing 11	The temperature sensor signal for the specified bearing is outside the defined sensor signal range. This measuring point is not available anymore for indication or monitoring. Configured safety functions related to this signal are not available anymore.
BVNG/GLNG	0010.016101.215.001.2	SD P-Raw Water	The pressure sensor signal for the raw water pressure monitoring is outside the defined sensor signal range. This measuring point is not available anymore for indication or monitoring. Configured (safety) functions related to this signal are not available anymore.
BVNG/GLNG	0010.025601.215.011.2	SD T-Splash Oil B1	The signal of the sensor measuring the temperature of the conrod bearing splash oil at position 1 at the B-side of the crank case is out of the plausible range and detected as defective.
BVNG/GLNG	0010.025601.215.021.2	SD T-Splash Oil B2	The signal of the sensor measuring the temperature of the conrod bearing splash oil at position 2 at the B-side of the crank case is out of the plausible range and detected as defective.
BVNG/GLNG	0010.025601.215.031.2	SD T-Splash Oil B3	The signal of the sensor measuring the temperature of the conrod bearing splash oil at position 3 at the B-side of the crank case is out of the plausible range and detected as defective.
BVNG/GLNG	0010.025601.215.041.2	SD T-Splash Oil B4	The signal of the sensor measuring the temperature of the conrod bearing splash oil at position 4 at the B-side of the crank case is out of the plausible range and detected as defective.
BVNG/GLNG	0010.025601.215.051.2	SD T-Splash Oil B5	The signal of the sensor measuring the temperature of the conrod bearing splash oil at position 5 at the B-side of the crank case is out of the plausible range and detected as defective.
BVNG/GLNG	0010.025601.215.061.2	SD T-Splash Oil B6	The signal of the sensor measuring the temperature of the conrod bearing splash oil at position 6 at the B-side of the crank case is out of the plausible range and detected as defective.

	Zeichnungs-Nr./Drawing No.	ZNG00046770	Blatt/ Sheet 9 von/of 185
	Material-Nr./Material No.	XZ00E52000043	

Alle Rechte aus Schutzrechtsanmeldungen vorbehalten. Weitergabe, Vervielfältigung oder sonstige Verwertung ohne Zustimmung nicht gestattet. Zuwiderhandlungen verpflichten zum Schadensersatz.
 All industrial property rights reserved. Disclosure, reproduction or use for any other purpose is prohibited unless our express permission has been given. Any infringement results in liability to pay damages.

Aenderungsbeschreibung/Description of Revision war KZ		Kommt vor/Frequency
Buchst./Rev.Ltr. -5	Aenderungs-Nr./Revision Notice No. PR099357	Bearbeitungsstatus/Lifecycle Freigegeben

Product	SysID	Alarm Name	Alarm Description
BVNG/GLNG	0010.025601.215.071.2	SD T-Splash Oil B7	The signal of the sensor measuring the temperature of the conrod bearing splash oil at position 7 at the B-side of the crank case is out of the plausible range and detected as defective.
BVNG/GLNG	0010.025601.215.081.2	SD T-Splash Oil B8	The signal of the sensor measuring the temperature of the conrod bearing splash oil at position 8 at the B-side of the crank case is out of the plausible range and detected as defective.
BVNG/GLNG	0010.025601.215.091.2	SD T-Splash Oil B9	The signal of the sensor measuring the temperature of the conrod bearing splash oil at position 9 at the B-side of the crank case is out of the plausible range and detected as defective.
BVNG/GLNG	0010.025601.215.101.2	SD T-Splash Oil B10	The signal of the sensor measuring the temperature of the conrod bearing splash oil at position 10 at the B-side of the crank case is out of the plausible range and detected as defective.
BVNG/GLNG	0010.050201.205.001.2	AL Battery Charger Failure	The voltage of the generator excitation supply (D+) is too low in comparison to the battery voltage (B+) while engine is running. The basic excitation current will flow from B+ to D+. This current is monitored. If engine is running the voltage at D+ should be about the battery voltage (B+) and no current should flow between B+ and D+. In old plants the current flow through the battery charger control lamp. The illuminated lamp indicated that the battery is not charged. If the engine is not running it is expected, that the voltage of D+ is well below B+ and a current should flow through the monitoring device. If the current is too low, when the engine is not running, indicates that there is a wiring problem between the battery, the generator and the monitoring device. The monitoring of the battery charger if the engine is not running is optional and can be disabled. It might be useful to disable the extended battery charger monitoring, if the battery is regularly disconnected from the engine, but keeping the monitoring system operative because disconnecting the battery would cause an alarm.
BVNG/GLNG	0010.050001.205.011.2	AL MMS Internal Power Fail	An internal power supply of the motor management system (engine governor and all engine mounted devices) failed. There might be a short circuit at a MMS output. Refer for details to the Engine Interface Module (EIM) documentation. A diagnostic lamp at the EIM will indicate more details.
BVNG/GLNG	0010.050002.205.011.2	AL MMS Main Power Fail	The main power supply of the motor management system (MMS) connected to the EIM failed. The system is still full operative and is feed through the emergency power supply.
BVNG/GLNG	0010.050002.205.021.2	AL MMS Emerg Power Fail	The emergency power supply of the motor management system (MMS) connected to the EIM failed. The system is still full operative and is feed through the main power supply.
BVNG/GLNG	0010.050003.105.011.2	LO Starter Supply Voltage	The starter supply voltage is below the minimum limit. The starter supply voltage is not monitored during the start procedure.
BVNG/GLNG	0010.043602.205.001.2	AL Shut Down Air Flaps Fail	Any error was detected in the shut down air flaps (SDAF) control. (Open circuits, unexpected feedback, short circuits ...). Shut down air flaps are optional.
BVNG/GLNG	0010.043601.205.001.2	AL Shut Down Air Flaps closed	At least one shut down air flap feedback switch was detected as activated. Shut down air flaps are optional.
BVNG/GLNG	0010.043305.205.001.2	AL Emerg. Stop Circuit Fail	Any error was detected in the emergency stop circuit. Possible failures might be open circuits between the emergency stop control circuit located in the EIM and the governor or emergency stop buttons. There might be also an internal failure inside the EIM. Refer to the EIM documentation.
BVNG/GLNG	0010.043307.205.001.2	AL Emergency Stop	An emergency stop was initiated. The emergency stop might be triggered manually or by external devices connected to an emergency stop input. (ECU, Safety System, External customer device connected at an emergency stop input at the yard interface.) An emergency stop will deactivate directly the injector power stage. This function is totally independent to the ECU software function.
BVNG/GLNG	0010.040105.205.001.2	AL Priming Pump Fail	A failure of the priming control circuit was detected. Either the pump was not running when expected or the priming starter box was set to off or the over current device was triggered.
BVNG	0010.040702.205.001.2 0010.040701.205.001.2	AL Starter Fail	A failure in the starter control circuit was detected. Open loop, short circuit?
BVNG/GLNG	0010.040801.205.001.2	AL Barring Gear Engaged	The limit switch, mounted at the cover of turning gear connection, indicates that the turning gear connection cover was removed. It is assumed that the turning device is manually engaged. Because the mechanic is in danger if the engine would be started, this alarm will cause a start interlock. This is for additional safety only. When working at the engine, the system has to be completely switched off!
BVNG/GLNG	0010.060301.205.001.2	AL EIM defect	An internal defect of the EIM was detected by the EIM itself.
BVNG/GLNG	0010.025401.105.001.2	LO P-Oil Refill Pump	The oil pressure after the oil refill pump which is pumping oil out and back into the oil pan was low for a certain period (several minutes). As long as the pump is able to pump oil out and back into the oil pan, there is enough oil in the engine. If the oil level is below the end of the "pump snorkel" the pump will not produce pressure within a certain time and this alarm will be triggered.
BVNG/GLNG	0010.007101.105.001.2	LO P-Start Air	The pressure for the air starter is too low.
BVNG/GLNG	0010.007101.115.001.2	LOLO P-Start Air	The pressure for the air starter is very low and a start is interlocked. The limit for that alarm should be set in a way that air for at least one start is remaining. This is to prevent emptying the air supply by (automatic) repeated starts. The start interlock can be disabled by activating "Override"
BVNG/GLNG	0010.025401.215.001.2	SD P-Oil Refill Pump	The pressure sensor signal for the oil refill pump pressure monitoring is outside the defined sensor signal range. This measuring point is not available anymore for indication or monitoring. Configured (safety) functions related to this signal are not available anymore.
BVNG/GLNG	0010.007101.215.001.2	SD P-Start Air	The pressure sensor signal for the start air pressure monitoring is outside the defined sensor signal range. This measuring point is not available anymore for indication or monitoring. Configured (safety) functions related to this signal (start interlock if start air pressure is too low) are not available anymore.

	Zeichnungs-Nr./Drawing No.	ZNG00046770	Blatt/ Sheet 10 von/of 185
	Material-Nr./Material No.	XZ00E52000043	
Alle Rechte aus Schutzrechtsanmeldungen vorbehalten. Weitergabe, Vervielfältigung oder sonstige Verwertung ohne Zustimmung nicht gestattet. Zuwiderhandlungen verpflichten zum Schadensersatz. All industrial property rights reserved. Disclosure, reproduction or use for any other purpose is prohibited unless our express permission has been given. Any infringement results in liability to pay damages.			